




# SERVICE MANUAL



## SPLIT TYPE ROOM AIR CONDITIONERS

**MODELS INDOOR UNIT      OUTDOOR UNIT**  
**AY-XP12JHR-N    AE-X12JR-N**

In the interests of user-safety (Required by safety regulations in some countries) the set should be restored to its original condition and only parts identical to those specified should be used.

### CONTENTS

#### CHAPTER 1. SPECIFICATION

[1] SPECIFICATION.....	1-1
[2] EXTERNAL DIMENSION .....	1-2
[3] WIRING DIAGRAM .....	1-3
[4] ELECTRICAL PARTS .....	1-3

#### CHAPTER 2. EXPLANATION OF CIRCUIT AND OPERATION

[1] BLOCK DIAGRAMS.....	2-1
[2] MICROCOMPUTER CONTROL SYSTEM....	2-3
[3] FUNCTION.....	2-9

#### CHAPTER 3. FUNCTION AND OPERATION OF PROTECTIVE PROCEDURES

[1] PROTECTION DEVICE FUNCTIONS AND OPERATIONS.....	3-1
[2] AIR CONDITIONER OPERATION IN THERMISTOR ERROR .....	3-3
[3] THERMISTOR TEMPERATURE CHARACTERISTICS .....	3-5
[4] HOW TO OPERATE THE OUTDOOR UNIT INDEPENDENTLY.....	3-6

[5] GENERAL TROUBLESHOOTING CHART....	3-6
[6] MALFUNCTION (PARTS) CHECK METHOD .....	3-8
[7] OUTDOOR UNIT CHECK METHOD.....	3-10
[8] TROUBLESHOOTING GUIDE .....	3-13

#### CHAPTER 4. REFRIGERATION CYCLE

[1] FLOW FLOW REFRIGERANT .....	4-1
[2] STANDARD CONDITION .....	4-1
[3] TEMPERATURE AT EACH PART AND PRESSURE IN 3-WAY VALVE .....	4-1
[4] PERFORMANCE CURVES.....	4-2

#### CHAPTER 5. DISASSEMBLING PROCEDURE

[1] DISASSEMBLY OF INDOOR UNIT .....	5-1
[2] DISASSEMBLY OF OUTDOOR UNIT .....	5-10

#### Parts Guide

# CHAPTER 1. SPECIFICATION

## [1] SPECIFICATION


### 1. AY-XP12JHR-N – AE-X12JR-N

ITEMS		MODEL	INDOOR UNIT AY-XP12JHR-N	OUTDOOR UNIT AE-X12JR-N		
Rated cooling capacity (Min– Max.)		kW	3.5 (0.9 - 4.0)			
Rated heating capacity (Min–Max.)		kW	4.6 (0.9 - 6.5)			
Moisture removal (at cooling)		Liters/h	1.2			
Electrical data						
Phase		Single				
Rated frequency		Hz	50			
Rated voltage		V	220-240			
Rated current ☆ (Min - Max.)	Cool	A	4.2 (0.9 - 5.7 )			
	Heat	A	5.0( 0.9 - 7.4 )			
Rated input ☆ (Min - Max.)	Cool	W	920 (200- 1250)			
	Heat	W	1075 (160 - 1700)			
Power factor ☆	Cool	%	95			
	Heat	%	93			
Maximum operating current		A	9.6			
Compressor	Type	Hermetically sealed rotary type				
	Model	DA11A1F22F				
	Oil charge	450cc (Ester oil VG74)				
Refrigerant system	Evaporator	Louver Fin and Grooved tube type				
	Condenser	Corrugate Fin and Grooved tube type				
	Control	Expansion valve				
	Refrigerant (R410A)	1140g				
	De-Ice system	Micro computer controled reversed systems				
Noise level (at cooling/heating)	High	dB(A)	40	47		
	Low	dB(A)	–	–		
	Soft	dB(A)	27	–		
Fan system						
Drive		Direct drive				
Air flow quantity (at cooling/heating)	High	m3/min.	9.3	32.2		
	Low	m3/min.	7.6	–		
	Soft	m3/min.	5.2	–		
Fan		Cross flow fan	Propeller fan			
Connections						
Refrigerant coupling		Flare type				
Refrigerant tube size Gas, Liquid		3/8", 1/4"				
Drain piping mm		O.D φ18				
Others						
Safety device		Compressor: Thermal protector				
		Fan motors: Thermal fuse				
		Fuse, Micro computer control				
Air filters		Polypropylene net (Washable)				
Net dimensions	Width	mm	790	780		
	Height	mm	260	540		
	Depth	mm	290	265		
Net weight		kg	11	36		


NOTE: The conditions of star"☆" marked item are based on 'EN14511'.

## [2] EXTERNAL DIMENSION

### 1. Indoor unit




### 2. Outdoor unit




### [3] WIRING DIAGRAM

#### 1. Indoor unit



#### 2. Outdoor unit



### [4] ELECTRICAL PARTS

#### 1. Indoor unit

DESCRIPTION	MODEL	REMARKS
Indoor fan motor	MLB395	DC Motor
Indoor fan motor capacitor	-	-
Transformer	-	-
FUSE1	-	QFS-GA078JBZZ (250V, 3.15A)


#### 2. Outdoor Unit

DESCRIPTION	MODEL	REMARKS
Compressor	DA111A1F22F	D.C. brush-less motor
Outdoor fan motor	MLB078	DC Motor
Outdoor fan motor capacitor	-	-
Fu4	-	QFS-GA064JBZZ(250V, 1A)
Fu3	-	QFS-GA051JBZZ(250V, 2A)
Fu2	-	QFS-GA052JBZZ(250V, 3.15A)
Fu1	-	QFS-CA001JBZZ(250V, 20A)
Fu5, 6	-	QFS-CA002JBZZ(250V, 15A)


## CHAPTER 2. EXPLANATION OF CIRCUIT AND OPERATION

### [1] BLOCK DIAGRAMS

#### 1. Indoor unit




## 2. Outdoor unit




## [2] MICROCOMPUTER CONTROL SYSTEM

### 1. Indoor unit

#### 1.1. Electronic control circuit diagram




## 1.2. Display circuit diagram




### 1.3. Printed wiring board

**For JHR-N model main PWB**




**For JHR-N model sensor PWB**




**To main PWB**

For JHR-N model connection PWB




For JHR-N model display PWB




## 2. Outdoor unit

### 2.1. Electronic control circuit diagram

**AE-X12JR-N CIRCUIT DIAGRAM**



## 2.2. Printed wiring board



## [3] FUNCTION


### 1. Function

#### 1.1. Restart control

Once the compressor stops operating, it will not restart for 180 seconds to protect the compressor.

Therefore, if the operating compressor is shut down from the remote control and then turned back on immediately after, the compressor will restart after a preset delay time.


(The indoor unit will restart operation immediately after the ON switch is operated on the remote control.)



#### 1.2. Cold air prevention control

When the air conditioner starts up in heating mode, the indoor unit fan will not operate until the temperature of the indoor unit heat exchanger reaches about 23°C in order to prevent cold air from blowing into the room.

Also, the indoor unit fan operates at low speed until the temperature of the indoor unit heat exchanger reaches about 38°C so that people in the room will not feel chilly air flow.



#### 1.3. Indoor unit heat exchanger freeze prevention control

If the temperature of the indoor unit heat exchanger remains below 0°C for 4 consecutive minutes during cooling or dehumidifying operation, the compressor operation stops temporarily in order to prevent freezing.

When the temperature of the indoor unit heat exchanger rises to 2°C or higher after about 180 seconds, the compressor restarts and resumes normal operation.

#### 1.4. Outdoor unit 2-way valve freeze prevention control

If the temperature of the outdoor unit 2-way valve remains below 0°C for 10 consecutive minutes during cooling or dehumidifying operation, the compressor operation stops temporarily in order to prevent freezing.

When the temperature of the 2-way valve rises to 10°C or higher after about 180 seconds, the compressor restarts and resumes normal operation.

#### 1.5. Indoor unit overheat prevention control

During heating operation, if the temperature of the indoor unit heat exchanger exceeds the indoor unit heat exchanger overheat prevention temperature (about 45 to 54°C) which is determined by the operating frequency and operating status, the operating frequency is decreased by about 4 to 15 Hz. Then, this operation is repeated every 60 seconds until the temperature of the indoor unit heat exchanger drops below the overheat protection temperature.

Once the temperature of the indoor unit heat exchanger drops below the overheat protection temperature, the operating frequency is increased by about 4 to 10 Hz every 60 seconds until the normal operation condition resumes.

If the temperature of the indoor unit heat exchanger exceeds the overheat protection temperature for 60 seconds at minimum operating frequency, the compressor stops operating and then restarts after about 180 seconds, and the abovementioned control is repeated.

#### 1.6. Outdoor unit overheat prevention control

During cooling operation, if the temperature of the outdoor unit heat exchanger exceeds the outdoor unit heat exchanger overheat prevention temperature (about 55°C), the operating frequency is decreased by about 4 to 15 Hz. Then, this operation is repeated every 60 seconds until the temperature of the outdoor unit heat exchanger drops to about 54°C or lower.

Once the temperature of the outdoor unit heat exchanger drops to about 54°C or lower, the operating frequency is increased by about 4 to 10 Hz every 60 seconds until the normal operation condition resumes.

If the temperature of the outdoor unit heat exchanger exceeds the outdoor unit heat exchanger overheat protection temperature for (120 sec : outdoor temperature ≥ 40°C • 60 sec : outdoor temperature < 40°C) at minimum operating frequency, the compressor stops operating and then restarts after about 180 seconds, and the abovementioned control is repeated.

#### 1.7. Compressor overheat prevention control

If the temperature of the compressor exceeds the compressor overheat prevention temperature (110°C), the operation frequency is decreased by about 4 to 10 Hz. Then, this operation is repeated every 60 seconds until the temperature of the compressor drops below the overheat protection temperature (100°C).

Once the temperature of the compressor drops below the overheat protection temperature, the operating frequency is increased by about 4 to 10 Hz every 60 seconds until the normal operation condition resumes.

If the temperature of the compressor exceeds the overheat protection temperature (for 120 seconds in cooling operation or 60 seconds in heating operation) at minimum operating frequency, the compressor stops operating and then restarts after about 180 seconds, and the abovementioned control is repeated.

#### 1.8. Startup control

When the air conditioner starts in the cooling or heating mode, if the room temperature is 2°C higher than the set temperature (in cooling operation) or 3.5°C lower (in heating operation), the air conditioner operates with the operating frequency at maximum. Then, when the set temperature is reached, the air conditioner operates at the operating frequency determined by fuzzy logic calculation, then enters the normal control mode after a while.

## 1.9. Peak control

If the current flowing in the air conditioner exceeds the peak control current the operation frequency is decreased until the current value drops below the peak control current regardless of the frequency control demand issued from the indoor unit based on the room temperature.


## 1.10. Outdoor unit fan delay control

The compressor stops immediately after cooling, dehumidifying or heating operation is shut down, but the outdoor unit fan continues operation for 50 seconds before it stops.

## 1.11. Defrosting

### 1.11.1 Reverse defrosting

The defrost operation starts when the compressor operating time exceeds 20 minutes during heating operation, as shown below, and the outside air temperature and the outdoor unit heat exchanger temperature meet certain conditions. When the defrost operation starts, the indoor unit fan stops. The defrost operation stops when the outdoor unit heat exchanger temperature rises to about 13°C or higher or the defrosting time exceeds 10 minutes.



## 1.12. ON timer


The ON timer can be activated by pressing the ON timer button. When the ON timer is activated, the operation start time is adjusted based on fuzzy logic calculations 1 hour before the set time so that the room temperature reaches the set temperature at the set time.

## 1.13. OFF timer


The OFF timer can be activated by pressing the OFF timer button. When the OFF timer is set, the operation stops after the set time.

When this timer is set, the compressor operating frequency lowers for quieter operation, and the room temperature is gradually varied after one hour (reduced 1°C three times (max. 3°C) in heating, or increased 0.3°C three times (max. 1°C) in cooling or dehumidifying operation) so that the room temperature remains suitable for comfortable sleeping.

### Heating operation



### Cooling/dehumidifying operation



## 1.14. Power ON start

If a jumper cable is inserted in the location marked with HAJP on the indoor unit control printed circuit board (control PCB), connecting the power cord to an AC outlet starts the air conditioner in either cooling or heating mode, which is determined automatically by the room temperature sensor.

When a circuit breaker is used to control the ON/OFF operation, please insert a jumper as described above.

## 1.15. Self-diagnostic malfunction code display

### 1.15.1 Indoor unit

- 1) When a malfunction is confirmed, a flashing malfunction code number is displayed to indicate the type of malfunction.

When the air conditioner is in non-operating condition, holding down AUX button for more than 5 seconds activates the malfunction code display function.

The operation continues only in the case of a serial open-circuit, and the main relay turns off after 30 seconds if the open-circuit condition remains.

In the case of a serial short-circuit, the air conditioner continues operating without a malfunction code display.

The malfunction information is stored in memory, and can be recalled later and shown on display.


- 2) The self-diagnostic memory can be recalled and shown on the display by stopping the operation and holding down AUX button for more than 5 seconds.
- 3) The content of self-diagnosis (malfunction mode) is indicated by a flashing number.

(For details, refer to the troubleshooting section.)

### 1.15.2 Outdoor unit

If a malfunction occurs, LED1 on the outdoor unit flashes in 0.2-second intervals as shown below.

#### (Example) Compressor high temperature abnormality



## 1.16. Information about auto mode

In the AUTO mode, the temperature setting and mode are automatically selected according to the room temperature and outdoor temperature when the unit is turned on.


Modes and Temperature Settings					
		outdoor temp. (°C)			
		0	10	18	28
29	Heat (24°C)	Heat (23°C)	Cool (24°C)	Cool (25°C)	Cool (26°C)
21	Set temperature	+0.3°C	+0.3°C	Dry (Room temp. -2°C)	Heat (22°C)

indoor temp. (°C) the figures in ( ) are temperature settings


During operation, if the outdoor temperature changes, the temperature settings will automatically slide as shown in the chart.

## 1.17. Adjusting the air flow direction


### 1.17.1 Vertical air flow direction




**1** Press the VERTICAL AIR FLOW button to set the desired air flow direction.





#### AUTO mode





#### HEAT mode



#### COOL/DRY mode



**1** Press the HORIZONTAL AIR FLOW button to set the desired air flow direction



#### CAUTION:

Never attempt to adjust the open panel and the louvres manually.

- Manual adjustment of the open panel and the louvres can cause the unit to malfunction.

### TIPS ABOUT AIR FLOW DIRECTION “AUTO”

#### COOL mode


The open panel will be set obliquely downward for 10 minutes, and then shift to obliquely upward to deliver cool air to the ceiling.

#### HEAT mode


The open panel will be set obliquely backward when outlet air temperature is low, and then shift to obliquely downward when outlet air becomes warm. When the room becomes warm, it will be set downward to deliver the warm air to the floor.

#### DRY mode


The open panel will be set obliquely upward.




When outlet air temperature is low



When outlet air becomes warm



When room becomes warm



## 1.18. Difference of operation in Auto and Manual modes

In the Auto mode, the temperature setting is automatically determined based on the outside air temperature. In addition, the air conditioner operation differs from the operation in the Manual mode as explained below.

### 1.18.1 Difference relating to set temperature

	Auto mode			Manual mode		
	Cooling	Heating	Dehumidifying	Cooling	Heating	Dehumidifying
Temperature setting method	Automatic temperature setting based on outside air temperature. Can be changed within $\pm 2^{\circ}\text{C}$ using remote control.			Can be changed between 18 and $32^{\circ}\text{C}$ using remote control.	Can be changed between 18 and $32^{\circ}\text{C}$ using remote control.	Automatic setting. Can be changed within $\pm 2^{\circ}\text{C}$ .

### 1.19. Dehumidifying operation control

If the room temperature is  $26^{\circ}\text{C}$  or higher when dehumidifying operation starts, the dehumidifying operation provides a low cooling effect in accordance with the room temperature setting automatically determined based on the outside air operation. (The setting value is the same as the set temperature for cooling operation in the auto mode.)


If the room temperature is lower than  $26^{\circ}\text{C}$  when dehumidifying operation starts, the dehumidifying operation minimizes the lowering of the room temperature.

### 1.20. Self Clean operation

Heating or Fan operation and Cluster operation are performed simultaneously.

The judgment of whether Heating or Fan operation is used is based on the outside air temperature at 3 minutes after the start of internal cleaning.

The operation stops after 40 minutes. (The air conditioner shows the remaining minutes: 40 → 39 → 38 ... 3 → 2 → 1)



### 1.21. Plasmacluster Ion function

Operating the Plasmacluster Ion button while the air conditioner is in operation or in non-operation allows the switching of the operation mode in the following sequence: "Air Clean operation" → "Stop".

- "Self Clean operation" generates about equal amounts of (+)ions and (-)ions from the cluster unit to provide clean air.


If the Plasmacluster Ion generation function is operated together with the air conditioner operation, the indoor unit fan speed and louver direction are in accordance with the air conditioner settings.

If the Plasmacluster Ion generation function is used without operating the air conditioning function, the indoor unit fan operates at a very low speed and the upper louver is angled upward and the lower louver remains horizontal. (The airflow volume and direction can be changed by using the remote control.)

### 1.22. Hot keep

If the room temperature is in the Hot keep zone during heating, the compressor is turned off to prevent overheating.

ZONE	COMPRESSOR	FAN
Hot keep (When room temperature reaches setting temperature)	OFF	Ultra soft (Lower than Fan speed "soft")



### 1.23. Winter cool

Cooling operation is available during the winter season by the built in winter cool function.

Lower limit of outdoor temperature range is  $-10^{\circ}\text{C}$  DB.

When the outside air temperature is low, the outdoor unit fan operates at slower speed.

NOTE: Built-in protect device may work when outdoor temperature falls below  $21^{\circ}\text{C}$  DB., depending on conditions.

### 1.24. 10°C OPERATION

Heating operation with  $10^{\circ}\text{C}$  set temperature will be performed.

- 1) Press the MODE button of Remote controller and select HEAT mode.
- 2) Press the ON / OFF button to start HEAT operation.
- 3) Press the  $10^{\circ}\text{C}$  button.
  - The remote control will display  $10^{\circ}\text{C}$ .

#### TO CANCEL

Press the  $10^{\circ}\text{C}$  button again.

- $10^{\circ}\text{C}$  operation will also be cancelled when the operation mode is changed, or when the unit is turned off.

#### NOTE:

- $10^{\circ}\text{C}$  operation will not be available with heating operation automatically selected by AUTO mode.

### 1.25. Auto restart

When power failure occurs, after power is recovered, the unit will automatically restart in the same setting which were active before the power failure.

#### 1.25.1 Operating mode (Cool, Heat, Dry)

- Temperature adjustment (within  $2^{\circ}\text{C}$  range) automatic operation
- Temperature setting
- Fan setting
- Air flow direction
- Power ON/OFF
- Automatic operation mode setting
- Swing louvre
- Plasmacluster mode

#### 1.25.2 Setting not memorized

- Timer setting
- Full power setting
- Internal cleaning


#### 1.25.3 Disabling auto restart function

By removing (cutting) jumper 8 (JP8) on the printed circuit board (PCB), the auto restart function can be disabled.

## 2. Explanation of cluster circuit

The cluster unit generates cluster ions, which are circulated throughout the room by the air flow created by the blower fan (indoor unit fan motor) in the air conditioner unit.

- When microcomputer output turns "H," the IC13 output changes to "Lo," turning ON the SSR1 and applying 100 V to the cluster unit for the generation of cluster ions (positive and negative ions).




## 3. Outline of PAM circuit

### 3.1. PAM (Pulse Amplitude Modulation)

The PAM circuit varies the compressor drive voltage and controls the rotation speed of the compressor.


The IGBT shown in the block diagram charges the energy (electromotive force) generated by the reactor to the electrolytic capacitor for the inverter by turning ON and OFF.



When the IGBT is ON, an electric current flows to the IGBT via the reactor (L5) and diode bridge (DB2).

When the IGBT turns OFF, the energy stored while the IGBT was ON is charged to the voltage doubler capacitor via the diode bridge (DB1).

As such, by varying the ON/OFF duty of the IGBT, the output voltage is varied.



### 3.2. High power factor control circuit

This circuit brings the operating current waveform closer to the waveform of commercial power supply voltage to maintain a high power factor.

Because of the capacitor input, when the PAM circuit is OFF, the phase of the current waveform deviates from the voltage waveform as shown below.

To prevent this deviation, a current is supplied during the periods indicated by "O" in the diagram.


To determine the length of period to supply a current, the zero-cross timing of the AC input voltage is input to the microcomputer via the clock circuit.

The power source frequency is also determined at the same time.


The IGBT turns ON after the time length determined by the zero-cross point to supply a current to the IGBT via the reactor.

This brings the current waveform closer to the voltage waveform in phase.

As described above, the ON/OFF operation of the IGBT controls the increase/decrease of the compressor power supply voltage (DC voltage) to improve the compressor efficiency and maintain a high power factor by keeping the current phase closer to that of the supply voltage.



#### 3.2.1 Detailed explanation of PAM drive circuit sequence



#### 3.2.2 AC clock (zero-cross) judgment

- The clock circuit determines the time from one rising point of the clock waveform to the next rising point.
- The detected clock waveform is used to judge the power source frequency (50 Hz).
- The zero-cross of the AC voltage is judged as the rising of the clock waveform, as shown in the diagram above.

#### 3.2.3 IGBT ON start time (delay time B)

- Based on the zero-cross of the AC voltage, the IGBT turns ON after a delay time set according to the power source frequency.

#### 3.2.4 IGBT ON time (C)

- After the above delay time, the IGBT turns ON to supply a current to the reactor.
- The ON time of the IGBT determines the amount of energy (level of DC voltage rise) supplied to the reactor.

DC voltage level in each operation mode (varies depending on external load conditions)


- Cooling operation --- 260 to 280 V
- Heating operation --- 260 to 290 V

### 3.3. PAM protection circuit

To prevent excessive voltage of PAM output from damaging the IPM and electrolytic capacitor as well as the control printed circuit board (PCB), this circuit monitors the PAM output voltage and turns off the PAM control signal and PAM drive immediately when an abnormal voltage output is generated. At the same time, it shuts off the compressor operation.

The PAM output voltage is distributed to pin (4) of the comparator (IC8). If this voltage exceeds the reference voltage at pin (5) of the IC8, the output of the comparator (IC8) reverses (from H to L) and it is input to pin (38) of the microcomputer (IC1) to halt the PAM drive.

The protection voltage level is as follows.



### 3.3.1 Details of troubleshooting procedure for PAM

#### 1) PAM shutdown due to error

1) When the DC voltage detection circuit sends a signal exceeding the specified voltage to the microcomputer

DC voltage of 400 V or higher (detection circuit input voltage of about 8.4 V or higher) [IC8 pin (4)]

– When an error is detected

- PAM IGBT turns OFF.
- Compressor turns OFF.
- All units shut down completely when the error occurs four times.

2) When the outdoor unit clock waveform differs from the specified value immediately before the PAM IGBT turns ON

When there is no clock waveform input

When a clock signal of other specified power source frequency (50 Hz) is input

– When an error is detected

- PAM IGBT does not turn ON.
- Compressor operates normally.
- Complete shutdown does not occur.

#### 2) PAM error indication

In case of error "1)"

- An error signal is sent to the indoor unit as soon as an error is generated.
  - Malfunction No. 14-0 is indicated when the error code is called out by the indoor unit's self-diagnosis function.
- The LED on the outdoor unit flashes 14 times when an error is generated.
  - The LED continues flashing in the 14-time cycle even after the compressor stops operating.
  - The LED turns off (data is deleted from the memory) when the outdoor unit power is turned off.

In case of error "2)"

- An error signal is sent to the indoor unit as soon as an error is judged.
  - Malfunction No. 14-1 is indicated when the error code is called out by the indoor unit's self-diagnosis function.
- The LED on the outdoor unit flashes 14 times when an error is judged.
  - The LED on the outdoor unit flashes in normal pattern when the compressor stops operating.

(Compressor OFF from remote control)

\* When a user complains that the air conditioner does not provide sufficient cool air or warm air

In addition to conventional error-generating reasons, there is a possibility that the PAM IGBT does not turn ON even if the compressor is operating.

In that case, the DC voltage does not rise even though the compressor is operating.

– Check items

- Clock circuit check
- PAM IGBT check
- Fuse (Fu6) open-circuit check

## 4. Explanation of IPM drive circuit

The IPM for compressor drive is made by Mitsubishi Electric.

The power supply for the IPM drive and the shunt resistance for overcurrent detection, are provided outside the IPM.

### 4.1. IPM drive power supply circuit

The power supply for the upper-phase IGBT (HU, HV, HW) drive employs a bootstrap system, and provides power to the upper-phase IC.


The 15-V power supply for the lower-phase IC is provided by the control printed circuit board (PCB).

#### 4.1.1 Brief explanation of bootstrap system (single power drive system)

To supply power to the upper-phase IC, the microcomputer (IC1) turns ON the lower-phase IGBT (LU, LV, LW).



This results in a charging current that flows to the electrolytic capacitor of each upper-phase IC input and charges the bootstrap capacitor with a 15-V current.

The power supply for the subsequent stages is charged while the lower-phase IGBT is ON in ordinary compressor drive control.



#### 4.1.2 DC overcurrent detection circuit

When a current of about 25 A or higher flows through the shunt resistance (R49) on the control printed circuit board (PCB), the voltage at this resistance is input to IPM CIN pin (15). Then, the gate voltage of the lower-phase IGBT (LU, LV, LW) inside the IPM turns OFF to cut off the overcurrent. At the same time, an L output of more than 20 $\mu$ s. is generated from IPM FO pin (14), and this results in an L input to overcurrent detection input pin (34) of the microcomputer (IC1) and turns OFF the PWM signal output (IC1 pins (51) through (56)) to the IGBT gate.




## 5. 120° energizing control (digital position detection control)

This control system detects the digital position detection signal and adjusts the rate of acceleration/deceleration accordingly.

The motor's induced voltage waveform is input to the comparator in the form of PWM-switched pulse waveform, and a position detection signal is generated as a reference voltage equaling 1/2 of 280 VDC. However, since there is no induced voltage waveform when the PWM waveform is OFF, the microcomputer performs internal processing so that detection is enabled only when it is ON. Based on the detected position signal, actual PWM waveform output timing is determined. Since it does not use a filter circuit, the detection accuracy is high.


The microcomputer performs internal processing to cancel spike voltage during the regenerative process.

Furthermore, even if the induced voltage is low, position detection is still possible, thus allowing sensor-less operation at low rotation speed in the initial stage of operation. This reduces the starting current and improves the IPM reliability.



## 6. 180° Energizing Control

This is the control system to moderate the speed by the current phase difference for higher efficiency and lower noise of the compressor. The current phase difference control is the control system paid attention to the interrelation between efficiency and phase gap generated by the applied voltage of motor and current in the coil of motor as shown in the figure below.



Concept chart of the current phase difference control

This control is the V/F drive system independent of the location of rotor, detecting the phase difference between driving voltage phase and line current phase flowing in motor coil, and controls the modulation rate data to get the phase difference at the best efficiency.

# CHAPTER 3. FUNCTION AND OPERATION OF PROTECTIVE PROCEDURES

## [1] PROTECTION DEVICE FUNCTIONS AND OPERATIONS

Function		Operation				Self-diagnosis result display	
		Description	Detection period	Reset condition	Indoor unit error display	Indoor unit	Outdoor unit
1	Indoor unit fan lock	Operation stops if there is no input of rotation pulse signal from indoor unit fan motor for 1 minute.	When indoor unit fan is in operation	Operation OFF or ON	☆2	Yes	None
	Indoor unit fan rotation speed error	Operation stops if rotation pulse signal from indoor unit fan indicates abnormally low speed (about 300 rpm or slower).	When indoor unit fan is in operation	Operation OFF or ON	☆2	Yes	None
2	Indoor unit freeze prevention	Compressor stops if temperature remains below 0°C for 4 minutes.	When in cooling or dehumidifying operation	Automatic reset when heat exchanger temperature rises above freeze prevention temperature (2°C or higher)	—	None	None
3	2-way valve freeze prevention	Compressor stops if temperature of outdoor unit 2-way valve remains below 0°C for 10 continuous minutes during cooling or dehumidifying operation.	When in cooling or dehumidifying operation	Automatic reset when temperature of 2-way valve rises above 10°C.	None	Yes	Yes
4	Indoor unit heat exchanger overheat shutdown	Operating frequency lowers if indoor unit heat exchanger temperature exceeds overheat temperature during heating operation. Compressor stops if indoor unit heat exchanger temperature exceeds overheat temperature for 60 seconds at minimum frequency. Overheat temperature setting value indoor unit heat exchanger thermistor temperature: about 45 to 54°C	When in heating operation	Automatic reset after safety period (180 sec).	None	Yes	Yes
5	Outdoor unit heat exchanger overheat shutdown	Operation frequency lowers if outdoor unit heat exchanger temperature exceeds about 55°C during cooling operation. Compressor stops if outdoor unit heat exchanger temperature exceeds about 55°C for 120 seconds at minimum frequency.	When in cooling or dehumidifying operation	Automatic reset after safety period (180 sec).	None	Yes	Yes
6	Compressor discharge overheat shutdown	Operating frequency lowers if temperature of compressor chamber thermistor (TH1) falls below about 110°C. Compressor stops if temperature of compressor chamber thermistor (TH1) remains at about 110°C (for 120 seconds in cooling operation, or 60 seconds in heating operation) at minimum frequency.	When compressor is in operation	Automatic reset after safety period (180 sec).	None	Yes	Yes
7	Dehumidifying operation temporary stop	Compressor stops if outside air temperature thermistor is lower than about 16°C during dehumidifying operation.	When in dehumidifying operation	Automatic reset when outside air temperature rises above 16°C.	None	Yes	Yes
8	DC overcurrent error	Compressor stops if DC current of about 25 A or higher flows in IPM.	When compressor is in operation	Operation OFF or ON	Yes ☆1	Yes	Yes

Function		Operation				Self-diagnosis result display	
		Description	Detection period	Reset condition	Indoor unit error display	Indoor unit	Outdoor unit
9	AC overcurrent error	Operating frequency lowers if outdoor AC current exceeds peak control current value. outdoor stops if compressor AC current exceeds peak control current value at minimum frequency.	When compressor is in operation	Operation OFF or ON	Yes ☆1	Yes	Yes
10	AC overcurrent error in compressor OFF status	Indoor and outdoor units stop if outdoor AC current exceeds about 3 A while compressor is in non-operation status.	When compressor is in non-operation	Replacement of defective parts such as IPM	Yes ☆2	Yes	Yes
11	AC maximum current error	Compressor stops if coutdoor AC current exceeds 17 A.	When compressor is in operation	Operation OFF or ON	Yes ☆1	Yes	Yes
12	AC current deficiency error	Compressor stops if operating frequency is 50 Hz or higher and outdoor AC current is about 2.0 A or lower.	When compressor is in operation	Operation OFF or ON	Yes ☆1	Yes	Yes
13	Thermistor installation error or 4-way valve error	Compressor stops if high and low values of temperatures detected by outdoor unit heat exchanger thermistor (TH2) and 2-way valve thermistor (TH5) do not match operating cycle.	3 minutes after compressor startup	Operation OFF or ON	Yes ☆1	Yes	Yes
14	Compressor high temperature error	Compressor stops if compressor chamber thermistor (TH1) exceeds about 114°C, or if there is short-circuit in TH1.	When in operation	Operation OFF or ON	Yes ☆1	Yes	Yes
15	Outdoor unit heat exchanger thermistor short-circuit error	Compressor stops if there is short-circuit in outdoor unit heat exchanger thermistor (TH2).	At compressor startup	Operation OFF or ON	Yes ☆1	Yes	Yes
16	Outdoor unit outside air temperature thermistor short-circuit error	Compressor stops if there is short-circuit in outdoor unit outside air temperature thermistor (TH3).	At compressor startup	Operation OFF or ON	Yes ☆1	Yes	Yes
17	Outdoor unit suction thermistor short-circuit error	Compressor stops if there is short-circuit in outdoor unit suction thermistor (TH4).	At compressor startup	Operation OFF or ON	Yes ☆1	Yes	Yes
18	Outdoor unit 2-way valve thermistor short-circuit error	Compressor stops if there is short-circuit in outdoor unit 2-way valve thermistor (TH5).	At compressor startup	Operation OFF or ON	Yes ☆1	Yes	Yes
19	Outdoor unit heat exchanger thermistor open-circuit error	Compressor stops if there is open-circuit in outdoor unit heat exchanger thermistor (TH2).	At compressor startup	Operation OFF or ON	Yes ☆1	Yes	Yes
20	Outdoor unit outside air temperature thermistor open-circuit error	Compressor stops if there is open-circuit in outdoor unit outside air temperature thermistor (TH3).	At compressor startup	Operation OFF or ON	Yes ☆1	Yes	Yes
21	Outdoor unit suction thermistor open-circuit error	Compressor stops if there is open-circuit in outdoor unit suction thermistor (TH4).	At compressor startup	Operation OFF or ON	Yes ☆1	Yes	Yes
22	Outdoor unit 2-way valve thermistor open-circuit error	Compressor stops if there is open-circuit in outdoor unit 2-way valve thermistor (TH5).	At compressor startup	Operation OFF or ON	Yes ☆1	Yes	Yes
23	Outdoor unit discharge thermistor open-circuit error	Compressor stops if there is open-circuit in outdoor unit discharge thermistor (TH1).	At compressor startup	Operation OFF or ON	Yes ☆1	Yes	Yes
24	Serial signal error	Compressor stops if outdoor unit cannot receive serial signal from indoor unit for 30 seconds.	When in operation	Reset after reception of serial signal	None	None	None
25	Compressor start-up error	Compressor stops if compressor fails to start up.	At compressor startup	Operation OFF or ON	Yes ☆3	Yes	Yes

Function		Operation				Self-diagnosis result display	
		Description	Detection period	Reset condition	Indoor unit error display	Indoor unit	Outdoor unit
26	Compressor rotation error (at 120° energizing)	Compressor stops if there is no input of position detection signal from compressor or input is abnormal.	Compressor operating at 120° energizing	Operation OFF or ON	Yes ☆3	Yes	Yes
27	Outdoor unit DC fan error	Operation stops if there is no input of rotation pulse signal from outdoor unit fan motor for 30 seconds.	When outdoor unit fan is in operation	Operation OFF or ON	Yes ☆1	Yes	Yes
28	PAM overvoltage error	Compressor stops if DC voltage is 400 V or higher.	When in operation	Operation OFF or ON	Yes ☆1	Yes	Yes
29	PAM clock error	When power source frequency cannot be determined (at startup), or when power source clock cannot be detected for 1 continuous second (at startup).	At compressor startup, when in operation	Compressor continues operation without stopping.	None	Yes	Yes

☆1—The outdoor unit restarts four times before the indoor unit error is displayed (complete shutdown).

☆2—A single error judgment results in the display of the indoor unit error (complete shutdown).

☆3—The outdoor unit restarts eight times before the indoor unit error is displayed (complete shutdown).

## [2] AIR CONDITIONER OPERATION IN THERMISTOR ERROR

### 1. Indoor unit

Item	Mode	Control operation	When resistance is low (temperature judged higher than actual)	Short-circuit	When resistance is high (temperature judged lower than actual)	Open-circuit
Room temperature thermistor (TH1)	Auto	Operation mode judgment	Cooling mode is activated even if room temperature is low.	Cooling mode is activated in most cases.	Heating mode is activated even if room temperature is high.	Heating mode is always activated.
	Cooling	Frequency control	Room becomes too cold.	Air conditioner operates in full power even when set temperature is reached.	Room does not become cool.	Compressor does not operate.
	Dehumidifying	Room temperature memory Frequency control	Normal operation.	Room temperature is stored in memory as 31.0°C, and compressor does not stop.	Normal operation.	Room temperature is stored in memory as 18.5°C, and compressor does not operate.
	Heating	Frequency control	Room does not become warm.	Hot keep status results immediately after operation starts. Frequency does not increase above 30 Hz (40 Hz).	Room becomes too warm.	Air conditioner operates in full power even when set temperature is reached.
Heat exchanger thermistor (TH2)	Cooling Dehumidifying	Freeze prevention	Indoor unit evaporator may freeze.	Indoor unit evaporator may freeze.	Compressor stops occasionally.	Compressor does not operate.
	Heating	Cold air prevention	Cold air prevention deactivates too soon and cold air discharges.	Compressor operates at low speed or stops, and frequency does not increase.	Cold air prevention deactivates too slow.	Cold air prevention does not deactivate, and indoor unit fan does not rotate.

## 2. Outdoor unit

Item	Mode	Control operation	When resistance is low (temperature judged higher than actual)	Short-circuit	When resistance is high (temperature judged lower than actual)	Open-circuit
Compressor chamber thermistor (TH1)	Cooling Dehumidifying Heating	Expansion valve control and compressor protection	Compressor operates, but room does not become cool or warm (expansion valve is open).	Compressor high temperature error indication.	Layer short-circuit or open-circuit may result in compressor in normal operation.	Outdoor unit thermistor open-circuit error indication.
Heat exchanger thermistor (TH2)	Cooling Dehumidifying	Outdoor unit heat exchanger overheat prevention	Compressor operates at low speed or stops.	Outdoor unit thermistor short-circuit error indication.	Normal operation.	Outdoor unit thermistor open-circuit error indication.
	Heating	Expansion valve control Defrosting	Defrosting operation is not activated as needed, and frost accumulates on outdoor unit (expansion valve is closed).	Outdoor unit thermistor short-circuit error indication.	Defrosting operation is activated unnecessarily, and room does not become warm (expansion valve is open).	Outdoor unit thermistor open-circuit error indication.
Outside air temperature thermistor (TH3)	Auto	Operation mode judgment	Cooling mode is activated even if room temperature is low.	Outdoor unit thermistor short-circuit error indication.	Heating mode is activated even if room temperature is high.	Outdoor unit thermistor open-circuit error indication.
	Cooling Dehumidifying	Operation not affected	Normal operation.	Outdoor unit thermistor short-circuit error indication.	Normal operation.	Outdoor unit thermistor open-circuit error indication.
	Heating	Rating control Defrosting	Defrosting operation is activated unnecessarily.	Outdoor unit thermistor short-circuit error indication.	Defrosting operation is not activated, and frost accumulates on outdoor unit.	Outdoor unit thermistor open-circuit error indication.
Suction pipe thermistor (TH4)	Cooling Dehumidifying	Expansion valve control	Compressor operates, but room does not become cool (expansion valve is open).	Outdoor unit thermistor short-circuit error indication.	Frost accumulates on evaporator inlet section, and room does not become cool (expansion valve is closed).	Outdoor unit thermistor open-circuit error indication.
	Heating	Expansion valve control	Compressor operates, but room does not become warm (expansion valve is open).	Outdoor unit thermistor short-circuit error indication.	Frost accumulates on expansion valve outlet section, and room does not become warm (expansion valve is closed).	Outdoor unit thermistor open-circuit error indication.
2-way valve thermistor (TH5)	Cooling Dehumidifying	Expansion valve control	Frost accumulates on indoor unit evaporator and room does not become cool (expansion valve is closed).	Outdoor unit thermistor short-circuit error indication.	Compressor operates, but room does not become cool (expansion valve is open).	Outdoor unit thermistor open-circuit error indication.
	Heating	Operation not affected	Normal operation.	Outdoor unit thermistor short-circuit error indication.	Normal operation.	Outdoor unit thermistor open-circuit error indication.


### [3] THERMISTOR TEMPERATURE CHARACTERISTICS

#### 1. Indoor unit thermistor temperature characteristics


**Figure 1 Temperature properties of indoor thermistors**

Thermistor	Signal	Color
Room temperature	TH1	Yellow
Heat exchange	TH2	Orange

Room temperature  
thermistor TH1 (CN10 ① - ③)  
Heat exchange  
thermistor TH2 (CN11 ① - ②)



#### 2. Outdoor unit thermistor temperature characteristics



Thermistor	No.	Connector	Color
Compressor thermistor	TH1	No. (1) - No. (2)	Red
Heat exchanger thermistor	TH2	No. (3) - No. (4)	Orange
Outdoor air temperature thermistor	TH3	No. (5) - No. (6)	Green
Suction thermistor	TH4	No. (7) - No. (8)	Black
2-way valve thermistor	TH5	No. (9) - No. (10)	Yellow


Before measuring resistance,  
disconnect connectors from PWB.

## [4] HOW TO OPERATE THE OUTDOOR UNIT INDEPENDENTLY

### 1. Cooling in 40 Hz fixed mode

To operate the outdoor unit independently, short-circuit the sections indicated by arrows in the diagram below with an adapter, and apply 220-240 VAC between (1) and (N) on the terminal board of the outdoor unit. This allows the outdoor unit to be operated in cooling mode independently.

(Do not operate the outdoor unit in this condition for an extended period of time.)



## [5] GENERAL TROUBLESHOOTING CHART

### 1. Indoor unit does not turn on

Main cause	Inspection method	Normal value/condition	Remedy
Cracked PWB. (Cracked pattern)	Check visually.	There should be no cracking in PWB or pattern.	Replace PWB.
Open-circuit in FU1 (250 V, 3.15 A)	Check melting of FU1.	There should be no open-circuit.	Replace PWB.

### 2. Indoor unit fan does not operate

Main cause	Inspection method	Normal value/condition	Remedy
Open-circuit in heat exchanger thermistor (TH2) (in heating operation)	Measure thermistor resistance (dismount for check).	-1	Replace thermistor.
		There should be no open-circuit or faulty contact.	Replace thermistor.
Disconnected heat exchanger thermistor (TH2) (in heating operation)	Inspect connector on PWB. Check thermistor installation condition.	Thermistor should not be disconnected.	Install correctly.

### 3. Indoor unit fan speed does not change

Main cause	Inspection method	Normal value/condition	Remedy
Remote control is not designed to allow fan speed change in several operation mode.	Check operation mode.	Fan speed should change except during dehumidifying operation, ventilation, light dehumidifying operation, internally normal operation	Explain to user.

### 4. Remote control signal is not received

Main cause	Inspection method	Normal value/condition	Remedy
Batteries at end of service life.	Measure battery voltage.	2.5 V or higher (two batteries in series connection)	Install new batteries.
Batteries installed incorrectly.	Check battery direction.	As indicated on battery compartment.	Install batteries in indicated direction.
Lighting fixture is too close, or Fluorescent lamp is flickering in the room.	Turn off light and check.	Signal should be received when light is turned off.	Change light position or install new fluorescent lamp.
Sevick light (Hitachi) is used in the room.	Check room lights.	Signal may not be received sometimes due to effect of Sevick light.	Replace light or change position.
Operating position/angle are inappropriate.	Operate within range specified in manual.	Signal should be received within range specified in manual.	Explain appropriate handling to user.
Open-circuit or short-circuit in wiring of light receiving section.	Check if wires of light receiving section are caught.	Wires of light receiving section should not have any damage caused by pinching.	Replace wires of light receiving section.
Light receiving unit is defective	Check signal receiving circuit (measure voltage between terminals 8 and 10, 9 and 10 of connector CN17).	Tester indicator should move when signal is received.	Replace PWB.

Main cause	Inspection method	Normal value/condition	Remedy
Dew condensation on light receiving unit.	Check for water and rust.	Signal should be received within range specified in manual.	Take moisture-proof measure for lead wire outlet of light receiving section.

## 5. Louvers do not move

Main cause	Inspection method	Normal value/condition	Remedy
Caught in sliding section.	Operate to see if louvers are caught in place.	Louvers should operate smoothly.	Remove or correct catching section.
Disconnected connector (CN13, CN16, CN19) on relay PWB, louver motor side)	Inspect connectors.	Connectors or pins should not be disconnected.	Install correctly.
Contact of solder on PWB (connector section on PWB)	Check visually.	There should not be solder contact.	Correct contacting section.

## 6. There is noise in TV/radio

Main cause	Inspection method	Normal value/condition	Remedy
Grounding wires not connected properly.	Check grounding wire connections.	Grounding wires should be connected properly.	Connect grounding wires properly.
TV/radio is placed too close to outdoor unit.	Check distance between TV/radio and outdoor unit.	If TV/radio is placed too close, it may become affected by noise.	Move TV/radio away from outdoor unit.
Other than above.	Check for radio wave interference.		

## 7. Malfunction occurs

Main cause	Inspection method	Normal value/condition	Remedy
Malfunction caused by noise.	Check for radio wave interference.		

## 8. Compressor does not start

Main cause	Inspection method	Normal value/condition	Remedy
Erroneous inter-unit connection.	Check wiring between indoor and outdoor units.	Terminal board 1-N: 220-240 VAC, 50 Hz Terminal board 2: serial signal	Correct wiring.
Damaged IPM.	Check IPM continuity.	See [IPM check method] on page 3-10	Replace IPM.
Dried-up electrolytic capacitor.	Check electrolytic capacitor.	See [Inverter electrolytic capacitor (C9,C10) check method] on page 3-9	Replace electrolytic capacitor.
Blown outdoor unit fuse.	Check 20A fuse. Check 15A fuse.	Fuse should not be blown.	Replace fuse/diode bridge. Replace fuse. Replace outdoor unit PWB assembly.
Power supply voltage is too low.	Measure power supply voltage during startup.	230±10 VAC, 50 Hz	Make sure that power supply voltage is 200 V or higher.
Compressor lock.  •Temp. fuse of terminal is error •EEPROM error •AC Over current error	Supply current and touch compressor cover (sound absorbing material) to check if operation starts.  See (Diagnosis Function and display mode) on page 3-13	Compressor should start normally.  Malfunction display section (0-0) Compressor should start normally.	Apply external impact to compressor. Replace compressor.  •Replace terminal •Replace outdoor unit PWB •Replace outdoor unit PWB

## 9. Operation stops after a few minutes and restarts, and this process repeats

Main cause	Inspection method	Normal value/condition	Remedy
Dried-up electrolytic capacitor.	Measure 320VDC line voltage.	300 V or higher.	Replace electrolytic capacitor.
Layer short-circuit in expansion valve coil.	Measure resistance.	46±3Ω in each phase (at 20°C)	Replace coil.


CAUTION: If fuse FU1/FU4/FU5 (outdoor unit control circuit board) is blown, be careful of charging voltage in inverter electrolytic capacitor C9, C10.

To discharge stored electricity, unplug the power cord and connect the plug of a soldering iron (230VAC, 50W) between the positive and negative terminals of inverter electrolytic capacitor C9, C10.

## [6] MALFUNCTION (PARTS) CHECK METHOD

### 1. Procedure for determining defective outdoor unit IPM/compressor

The following flow chart shows a procedure for locating the cause of a malfunction when the compressor does not start up and a DC overcurrent indication error occurs.





**CAUTION:** Please take care for electrical shock when you work to change defective parts or disconnect wires of defective application.

The outdoor unit has energy changed for a while even after unplugging the power supply cord.

After changing the part or unit, please retry check procedure from the beginning.


## 2. Procedure for determining defective expansion valve



## 3. Diode bridge check method

Turn off the power and let the inverter electrolytic capacitor (C9, C10) discharge completely. Then use a tester and check continuity.

When using a digital tester, the (+) and (-) tester lead wires in the table must be reversed.



## 4. Inverter electrolytic capacitor (C9, C10) check method

Turn off the power, let the inverter electrolytic capacitor (C9, C10) discharge completely, and remove the capacitor from the control printed circuit board (PWB). First, check the case for cracks, deformation and other damages. Then, using a needle-type tester, check continuity.

### Determination of normal condition

The tester needle should move on the scale and slowly returns to the original position. The tester needle should move in the same way when polarities are reversed. (When measurement is taken with the polarities reversed, the tester needle exceeds the scale range. Therefore, let the capacitor discharge before measurement.)

## 5. IPM check method

Turn off the power, let the large capacity electrolytic capacitor (C10) discharge completely, and dismount the IPM. Then, using a tester, check leak current between C and E.


When using a digital tester, the (+) and (-) tester lead wires in the table must be reversed.

Needle-type tester		Normal resistance value
(-)	(+)	
P	N	$\infty$ (several M $\Omega$ )
	U	
	V	
	W	

Needle-type tester		Normal resistance value
(-)	(+)	
U	N	$\infty$ (several M $\Omega$ )
	V	
	W	

Values in ( ) are for digital tester.

### 5.1. IPM internal circuit diagram



## [7] OUTDOOR UNIT CHECK METHOD


After repairing the outdoor unit, conduct the following inspection procedures to make sure that it has been repaired completely. Then, operate the compressor for a final operation check.

### 1. Checking procedures

No.	Item	Check method	Normal value/condition	Remedy
1	Preparation	Disconnect compressor cords (white, orange, red: 3 wires) from compressor terminals, and connect simulated load (lamp used as load). Operate air conditioner in cooling or heating test operation mode.		
2	Inverter DC power supply voltage check	Measure DC voltage between IPM pins (20) and (24).	320 VDC	Replace control PWB. Replace diode bridge. Correct soldered section of Fasten tabs (BT1,2,5,6,10,11, JPL1,2,5,6) on control PWB. (Repair solder cracks.)

No.	Item	Check method	Normal value/condition	Remedy
3	IPM circuit check	Check that 3 lamps (load) light. Check position detection voltage (+15 V, 5 V) on control PWB.	Each voltage should be normal. All 3 lamps (load) should light with same intensity.	Replace control PWB.
4	Compressor check	Measure compressor coil resistance (for each phase of U, V and W). Use multi-meter or digital tester capable of displaying two digits right of the decimal point (0.01Ω).	Resistance value at 20°C --- 0.65Ω	Correct connections at compressor terminals. Replace compressor.
5	Expansion valve check	Measure expansion valve coil resistance.	Each phase 46±3Ω (at 20°C)	Replace expansion valve.
6	Final check	Turn off power, and connect compressor cords to compressor. Operate air conditioner. Measure DC voltage between IPM pins (20) and (24).	Compressor should operate normally. 320 VDC or higher.	Replace control PWB. Replace outdoor unit thermistor. Replace compressor (in case of compressor lock).

## 2. Troubleshooting of outdoor unit electric components





### 3. Caution in checking printed circuit boards (PWB)

#### 3.1. Non-insulated control circuit

The GND terminals of the low-voltage circuits (control circuits for microcomputer and thermistors and drive circuits for expansion valve and relays) on the control printed circuit board (PWB) are connected to the compressor drive power supply (320-VDC negative terminal). Therefore, exercise utmost caution to prevent electric shock.

If a measuring instrument used for the test is grounded, its chassis (ground) has the same electric potential as the 0-V probe. Since non-insulated circuits have the following voltage potential difference from the ground, connection of the grounding wire results in a short-circuit between the 0-V line and the ground, thus allowing an excessive current to flow to the tester to cause damage.

If the sheaths of the thermistor lead wires or expansion valve lead wires inside the outdoor unit become damaged due to pinching by the front panel or other metal parts or contacting a pipe, a high voltage can flow and destroy the circuits. To prevent these problems, carefully conduct assembly work.



## [8] TROUBLESHOOTING GUIDE

### 1. Self-Diagnosis Function and Display Mode

To call out the content of the self-diagnosis memory, hold down the emergency operation button for more than 5 seconds when the indoor unit is not operating.

- The number of indications displayed by the LEDs on the outdoor unit differs from that for the 2001 cooling unit models (for detailed display of malfunction information).


The display of malfunction No. differs from that of the 2001 cooling unit models. To show detailed malfunction information, two types of numbers flash alternately. (example: "21"  $\longleftrightarrow$  "-0")

1) The content of the self-diagnosis memory can be called out and displayed on the seven-segment display section on the indoor unit. (The error data cannot be called out for display by the LED on the outdoor unit.)

2) If the power cord is unplugged from the AC outlet or the circuit breaker is turned off, the self-diagnosis memory loses the stored data.

- The self-diagnosis display function of the indoor unit indicates the content of diagnosis by showing the error main category (number) and the error sub-category (-number) alternately in 1-second intervals on the seven-segment display section of the indoor unit.

Example of self-diagnosis display on indoor unit: Compressor high-temperature error




- b) The self-diagnosis display function of the outdoor unit indicates the error information by flashing LED1 on the outdoor unit according to the content of self-diagnosis.

The self-diagnosis display function of the outdoor unit is active only for about 3 to 10 minutes after self-diagnosis is performed during operation, and the display returns to normal condition after this display period.

The content of self-diagnosis cannot be called out by the self-diagnosis display function of the outdoor unit.

Example of self-diagnosis display on outdoor unit: Compressor high-temperature error



- c) The content of diagnosis is transferred to the indoor unit via serial communication, but it does not trigger a complete shutdown operation.

⦿ : Flashes in 2-sec intervals (normal), ●: On, ×: Off, ⚡: Flashes 3 times in 0.2-sec intervals (When LED1 on the outdoor unit flashes in 2-sec intervals, the outdoor unit is in normal condition.)

Status of indoor/outdoor units	Indication by LED1 on outdoor unit *2	Malfunction No. displayed on main unit display section *1		Content of diagnosis	Inspection location/method	Remedy
		Main category	Sub-category			
Indoor/outdoor units in operation	⦿ Normal flashing	0	0	Normal	-	-
Indoor/outdoor units in complete shutdown	⦿ 1 time	1	-0	Outdoor unit thermistor short-circuit error	(1) Measure resistance of the outdoor unit thermistors. (TH2 to TH5: Approx. 4.4 kΩ at 25°C)	(1) Replace the outdoor unit thermistor assembly.
			-1	Outside temperature thermistor short-circuit error	(2) Check the lead wire of the outdoor unit thermistor for torn sheath and short-circuit.	(2) Replace the outdoor unit thermistor assembly.
			-2	Suction thermistor short-circuit error	(3) No abnormality found in above inspections (1) and (2).	(3) Replace the outdoor unit control PWB assembly.
			-3	2-way valve thermistor short-circuit error		






Status of indoor/outdoor units	Indication by LED1 on outdoor unit *2	Malfunction No. displayed on main unit display section *1		Content of diagnosis	Inspection location/method	Remedy	
		Main category	Sub-category				
Indoor/outdoor units in complete shutdown	● 2 times	2	-0	Cycle temperature	Compressor high-temperature error	(1) Check the outdoor unit air outlet for blockage.  (2) Check if the power supply voltage is 200 V or higher at full power.  (3) Check the pipe connections for refrigerant leaks.  (4) Measure resistance of the outdoor unit compressor thermistor. (TH1: Approx. 53 kΩ at 25°C)  (5) Check the expansion valve for proper operation.	(1) Ensure unobstructed air flow from the outdoor unit air outlet.  (2) Connect power supply of proper voltage.  (3) Charge the specified amount of refrigerant.  (4) Replace the outdoor unit compressor thermistor assembly.  (5) Replace the expansion valve coil, expansion valve or outdoor unit control PWB assembly.
					Temporary stop due to compressor discharge overheat *3	(Temporary stop for cycle protection)	—
					Temporary stop due to outdoor unit heat exchanger overheat *3	(Temporary stop for cycle protection)	—
					Temporary stop due to outdoor unit heat exchanger overheat *3	(Temporary stop for cycle protection)	—
					Temporary stop due to 2-way valve freeze *3	(Temporary stop for cycle protection)	—
					Dry operation	Temporary stop due to dehumidifying operation *3	(Temporary stop for cycle protection)
Indoor unit in operation Outdoor unit in temporary stop	● 3 times	3	-0	Outdoor unit thermistor open-circuit	Heat exchanger thermistor open-circuit error	(1) Check connector CN8 of the outdoor unit thermistor for secure installation.  (2) Measure resistance of outdoor thermistors TH1 to TH5.  (3) Check the lead wires of thermistors TH1 to TH5 on the outdoor unit control PWB for open-circuit.  (4) No abnormality found in above inspections (1) through (3).	(1) Correct the installation.  (2) Replace the outdoor unit thermistor assembly.  (3) Replace the outdoor unit thermistor assembly.  (4) Replace the outdoor unit control PWB assembly.
					Outside temperature thermistor open-circuit error		
					Suction thermistor open-circuit error		
					2-way valve thermistor open-circuit error		
					Discharge thermistor open-circuit error		

Status of indoor/outdoor units	Indication by LED1 on outdoor unit *2	Malfunction No. displayed on main unit display section *1		Content of diagnosis	Inspection location/method	Remedy	
		Main category	Sub-category				
Indoor/outdoor units in complete shutdown	● 6 times	6	-0	Outdoor unit DC	DC over current error	(1) IPM continuity check  (2) Check the IPM and heat sink for secure installation.  (3) Check the outdoor unit fan motor for proper rotation.  (4) No abnormality found in above inspections (1) through (3).  (5) No abnormality found in above inspections (1) through (4).	(1) Replace the outdoor unit control PWB assembly.  (2) Correct the installation (tighten the screws).  (3) Replace the outdoor unit fan motor.  (4) Replace the outdoor unit control PWB assembly.  (5) Replace the compressor.
			-1		IPM pin level error	Check the IPM is attached correctly to the outdoor unit control PWB.	Replace the outdoor unit control PWB assembly.
Indoor/outdoor units in complete shutdown	● 7 times	7	-0	Outdoor unit AC	AC over current error	(1) Check the outdoor unit air outlet for blockage.  (2) Check the outdoor unit fan for proper rotation.	(1) Ensure unobstructed air flow from the outdoor unit air outlet.  (2) Check the outdoor unit fan motor.
			-1		AC over current error in OFF status	(1) IPM continuity check	(1) Replace the outdoor unit control PWB assembly.
			-2		AC maximum current error	(1) Check the outdoor unit air outlet for blockage.  (2) Check the outdoor unit fan for proper rotation.	(1) Ensure unobstructed air flow from the outdoor unit air outlet.  (1) Check the outdoor unit fan motor.
			-3		AC current deficiency error	(1) Check if there is an open-circuit in the secondary winding of the current transformer of the outdoor unit control PWB.  (2) Check if the refrigerant volume is abnormally low.  (3) Check if the refrigerant flows properly.	(1) Replace the outdoor unit control PWB assembly.  (2) Charge the specified amount of refrigerant.  (3) Correct refrigerant clogs. (2-way valve, 3-way valve, pipe, expansion valve)
Indoor/outdoor units in complete shutdown	● 9 times	9	-0	Outdoor unit cooling/heating switch over	Thermistor installation error or 4-way valve error	(1) Check to make sure outdoor unit thermistor TH2 (heat exchanger) and TH5 (2-way valve) are installed in correct positions.  (2) Measure resistance of thermistors TH1 and TH5.  (3) Check the 4-way valve for proper operation.  (4) No abnormality found in above inspections (1) through (3).	(1) Correct the installation.  (2) Replace the thermistor assembly.  (3) Replace the 4-way valve.  (4) Replace the outdoor unit control PWB assembly.
			-3		Torque control error	(1) Check if the refrigerant volume is abnormally low.  (2) Check the 4-way valve for proper operation.  (3) check to see compressor type is correct.	(1) Change the specified amount of refrigerant.  (2) Replace the 4-way valve.  (3) Replace the compressor with the correct part.

Status of indoor/outdoor units	Indication by LED1 on outdoor unit *2	Malfunction No. displayed on main unit display section *1		Content of diagnosis		Inspection location/method	Remedy
		Main category	Sub-category	Main category	Sub-category		
Indoor/outdoor units in complete shutdown	● 10 times	10	-0	EEPROM error	EEPROM (outdoor) error		(1) Replace the outdoor unit control PWB assembly.
			-1		EEPROM (outdoor) data error		
Indoor/outdoor units in complete shutdown	● 11 times	11	-0	Outdoor unit DC fan	Outdoor unit DC fan rotation error	(1) Check connector CN3 of the outdoor unit DC fan motor for secure installation. (2) Check the outdoor unit fan motor for proper rotation. (3) Check fuse FU3. (4) Outdoor unit control PWB	(1) Correct the installation. (2) Replace the outdoor unit fan motor. (3) Replace the outdoor unit control PWB assembly. (4) Replace the outdoor unit control PWB assembly.
Indoor/outdoor units in complete shutdown	● 12 times	12	-0	outdoor terminal board fuse	outdoor terminal board fuse open error	(1) Check connector CN10 for secure installation. (2) Check the fuse open of outdoor terminal board .	(1) Correct the installation. (2) Replace the outdoor terminal board.
Indoor/outdoor units in complete shutdown	● 13 times	13	-0	DC compressor	Compressor startup error	(1) Check the colors (red, white, orange) of the compressor cords for proper connection. (PWB side, compressor side)	(1) Correct the installation. (U: Red, V: White, W: Orange)
			-1		Compressor rotation error (120° energizing error)	(2) Check if the IPM terminal resistance values are uniform. (3) No abnormality found in above inspections (1) and (2). (4) No abnormality found in above inspections (1) through (3).	(2) Replace the outdoor unit control PWB assembly. (3) Replace the outdoor unit control PWB assembly. (4) Replace the compressor.
Indoor/outdoor units in complete shutdown	● 14 times	14	-0	Outdoor unit PAM	PAM over voltage error Compressor rotation error	(1) Check the AC power supply voltage for fluctuation. (2) No abnormality found in above inspection (1).	(1) Connect stable power supply. (2) Replace the outdoor unit control PWB assembly.
Indoor/outdoor units in operation			-1		PAM clock error	(1) Check the PAM clock for proper input.	(1) Replace the outdoor unit control PWB assembly.


Status of indoor/outdoor units	Indication by LED1 on outdoor unit *2	Malfunction No. displayed on main unit display section *1		Content of diagnosis		Inspection location/method	Remedy
		Main category	Sub-category	Main category	Sub-category		
Indoor unit in operation Outdoor unit in complete shutdown	●	17	-0	Wires between units	Serial open-circuit	(1) Check the wires between units. (2) Check voltage between Nos. 1 and 2 on the indoor/outdoor unit terminal boards.	(1) Connect stable power supply. (2) Replace the outdoor unit control PCB assembly.
	X				Outdoor unit does not turn on due to erroneous wiring	(1) Check the wires between units. (2) Check the outdoor unit fuse. (3) Check 15-V, 13-V and 5-V voltages on the PWB. Check resistance between IPM terminals. (4) Check pins No. 5 and 7 of connector CN3 of the outdoor unit fan motor for short-circuit. (5) Outdoor unit control PCB	(1) Correct the wiring. (2) Replace the fuse/outdoor unit control PCB assembly. (3) Replace the outdoor unit control PCB assembly. (4) Replace the outdoor unit fan motor. (5) Replace the outdoor unit control PCB board.
	●		18		Serial short-circuit	(1) Check the wires between units.	(1) Correct the wiring.
			-1		Serial erroneous wiring	(1) Check the wires between units.	(1) Correct the wiring.
	X	19	-0		Indoor unit fan	Indoor unit fan error	(1) Check the indoor fan motor for proper rotating operation.(Check fan lock.) (2) Check the lead wire of the indoor fan motor for open-circuit. (3) Check CN1 of the indoor unit fan motor for secure installation. (4) No abnormality found in above inspections (1) through (3).
Indoor/outdoor units in operation	X	20	-0		Indoor unit control PCB	EEPROM data error	(EEPROM read data error)
Indoor/outdoor units in operation	X	29	-0	Panel	Panel open error	(1) Caught of panel hook	(1) Replace or adjustment of the panel.
					Panel close error	(2) Limit switch breakdown	(2) Replace the limit switch.
Indoor/outdoor units in operation	X	88		Control and display PCB	Communication error	(1) Check for disconnected connector between control PCB and display PCB, and open-circuit in lead wires. (2) Check that control PCB outputs signals correctly.	(1) Insert connectors correctly, or replace control PWB. (2) Replace control PWB.

Malfunction indications due to erroneous wiring during air conditioner installation

Inter-unit wiring error mode	Symptom
1  Indoor unit      Outdoor unit	Malfunction diagnosis display "18-1"
2  Indoor unit      Outdoor unit	Malfunction diagnosis display None (Displays "18-0" when malfunction code is called out.)
3  Indoor unit      Outdoor unit	Malfunction diagnosis display None (Displays "18-0" when malfunction code is called out.)
4  Indoor unit      Outdoor unit	Malfunction diagnosis display "18-1"
5  Indoor unit      Outdoor unit	Malfunction diagnosis display "18-1"

## CHAPTER 4. REFRIGERATION CYCLE

### [1] FLOW FOW REFRIGERANT



### [2] STANDARD CONDITION

	Indoor side		Outdoor side	
	Dry-bulb Temp. (°C)	Relative Humidity (%)	Dry-bulb Temp. (°C)	Relative Humidity (%)
Cooling	27	47	35	40
Heating	20	-	7	87

\* REFRIGERANT PIPE LENGTH 5m

### [3] TEMPERATURE AT EACH PART AND PRESSURE IN 3-WAY VALVE

Model	AY-XP12JHR-N	
NO. Condition	Cooling	Heating
Temp. on ① (°C)	67	56
Temp. on ② (°C)	37	3
Temp. on ③ (°C)	14	22
Temp. on ④ (°C)	17	5
3-way valve pressure (MPaG)	1.00	2.09

\* On test run mode


## [4] PERFORMANCE CURVES

### NOTE




- 1) Indoor fan speed: Hi
- 2) Vertical adjustment louver "45°", Horizontal adjustment louver "front"
- 3) Indoor air temp. : Cooling 27°C, Heating 20°C
- 4) Power source : 230V, 50Hz

### 1. AY-XP12JHR-N

#### 1.1. At Cooling



#### 1.2. At Heating



## CHAPTER 5. DISASSEMBLING PROCEDURE

If, in carrying out repairs and modifications, the work requires the use of arc- and flame-producing apparatus, such as welding, brazing and soldering equipment, this work shall only be started after the rooms have been thoroughly ventilated. While the work is being carried out, the mechanical ventilation, if any, shall be kept in constant operation and all windows and doors kept open. In the case of repairs to parts of the refrigerant circuit, it may be necessary that not only the workman but also a second person shall be present for observation and assistance.

Necessary protective equipment shall be available and, in the case of open flames or arcs, fire extinguishing apparatus shall be ready to hand.

Welding and brazing shall be carried out by qualified workmen.

### [1] DISASSEMBLY OF INDOOR UNIT


Be sure to disconnect the power cord from the AC power outlet before starting the disassembly procedure. When reassembling the unit after repairing, be sure to install screws to their original positions.

The screws used are not the same in specifications such as corrosion-resistant treatment, tip shape and length.

After the air conditioner is repaired or parts are replaced, measure insulation resistance of the equipment using an insulation resistance meter. If the measured resistance is lower than  $1 \text{ M}\Omega$ , inspect parts and repair or replace defective parts.



1) The lock button on a lower both sides of the panel is pushed.

4) The filter cover is opened, and one screw at the center is removed.





2) The lower side of the panel is pulled forward.

5) The 2 screw covers are removed. (plunder the balloon entrance)



3) The panel is raised up and removed.

6) The 2 screws are removed.




# AYXP12JHRN


7) Remove the connector cover. (use the (-) screwdriver).



8) All of the nine connectors are removed.




9) The hook three places of the part interior of front panel on are removed.




10)Front panel is pulled to front this side and removed.



11)The tapes that is the fixation of the lead wire is peeled off.



12)The panel base is drawn out forward. (both sides)




13)The gear is turned, and the panel base is removed. For a minus screw driver etc.




14)The pin that is the fixation of the panel base and the link is removed.




15)The panel mechanism assembly is removed. (2 screws)




16)The display assembly is removed. (right and left two hooks place)




17)The cover of the display printed boad is removed.




18)The display panel is removed.



19)The display printed boad is removed. (Hook three places)



20)The panel mechanism cover is removed. (3 screws)



21)The screw that is the fixation of the panel motor is removed, and is turned to the left and it is removed.




22)The gear, the crank, and the arm are removed.




# AYXP12JHRN


23)The panel motor is removed. (2 screws)




24)The mechanism case is removed. (Hook one place)




25)The limit switch is removed.




26)The reception part is removed. (Hook two places)




27)The reception cover is removed.




28)The fixing band of the sub.printed boad assembly is cut.



29)The sub.printed boad assembly is removed. (2 screws)




30)Five connectors are removed from sub. printed boad.




31)The sub.printed board cover is removed. (Hook two places)



32)The sub.printed board is removed. (Hook two places)



33)A fixed screw for P.W.B. box cover is removed.




34)Hook is removed by handling a minus driver.




35)The P.W.B. box cover is removed.




36)The fixing band in the P.W.B.assembly is cut. (4 parts)



37)The connectors in nine places are removed.




38)The Terminal board removed. (1 screw )




# AYXP12JHRN


39)The plasmacluster assembly is removed. (2 screws)




40)The plasmacluster assembly is pulled forward, and detached.




41)Two hooks of the plasmacluster cover are removed by using (-) screwdriver.




42)After the plasmacluster that removes the PC cover is taken out, the wire connector is removed.




43)Six screws for the fixation of the air filter cleaning mechanism assembly is removed.




44)Air filter cleaning mechanism assembly is pulled forward and removed.



45)The limit switch cover is removed.



46)The limit switch is removed. (Hook one place)



47)The wire connector of the limit switch is removed.



48)The thermally sensitive resistor holder is removed.  
(Hook two places)



49)The relay printed bord holder removed. (2 screws)




50)P.W.B. assmbly is removed. (2 screws)




51)The earth cable is removed. (1 earth screw )




52)The P.W.B.assembly is drawn out forward.



53)The Terminal cover of the Terminal stand assembly is removed.  
(Hook two places)



54)The P.W.B. box cover is removed. (Hook one place) And the control bord unit is removed.




# AYXP12JHRN


55)The dew cover is removed. (The slide is done right and remove. )



56)Two screws of cover L are removed.



57)Two screws for the evaporator fixation (right side) are removed.




58)One screw for the drain pan fixation (right side) is removed.




59)The drain pan is detached.



60)Four fixed screws of the vertical direction louver stand assembly removed.




61)Driving motor of the vertical direction louver stand assembly is removed. (2 screws)




62)The bearing holder is removed. (1 screw)



63)The cross flow fan fixation screw is loosened.




64)The two screws for the fan motor cover fixation are removed.




65)The cross flow fan is pulled out at the left of the unit and it removes.

66)Fan motor is removed.




## [2] DISASSEMBLY OF OUTDOOR UNIT


- 1) The fixed screw of control box cover is removed and control box cover is removed.




- 2) The 2 screws on the right-hand side of top plate ass'y is removed.




- 3) The 2 screws on the left-hand side of top plate ass'y is removed.




- 4) The screw on the right-hand side of front panel is removed




- 5) The screw on the right-hand side of front panel is removed




- 6) The 4 screws of the front of a front panel is removed.




- 7) The 5 screws on the right-hand side of side cover R is removed.



8) The 2 screws on the right-hand side of side cover L is removed.




9) The 7 screws of the side cover L and side cover R back is removed.




10)The connectors in the control box BOX and reactor is removed.




11)A control box BOX fixed 2 screws is removed.



12)A bulkhead plate fixed 2 screws is removed.



13)The compressor covers 1, 2 removed.



14)A nut is removed and a terminal cover is removed.




15)A lead wire, a thermistor, and a cover gasket are removed.




16)The compressor cover is removed.




17)A thermistor is removed. (1 place)



18)An outdoor fan is removed.




19)The fixed 2 screws of a motor angle is removed.




**- Disassembly of Heater(CHET-A025JBKZ) Unit**


- 1) Cut the band fixing the bi-metal thermostat.
- 2) Powercord for bi-metal thermostat.



- 3) Cut the band which holds together the thermistor cords and power cord for bi-metal thermostat.
- 4) Remove screw NK-8K




- 5) Pull out the heater wire from beneath the heat exchanger





# PARTS GUIDE



## SPLIT TYPE ROOM AIR CONDITIONERS

**MODELS INDOOR UNIT      OUTDOOR UNIT**  
**AY-XP12JHR-N AE-X12JR-N**


In the interests of user-safety (Required by safety regulations in some countries) the set should be restored to its original condition and only parts identical to those specified should be used.

### CONTENTS

- |                                                     |                           |
|-----------------------------------------------------|---------------------------|
| [1] INDOOR UNIT PARTS                               | [5] OTHER PARTS           |
| [2] Panel opening and shutting mechanism R Assembly | [6] INDOOR PACKING PARTS  |
| [3] Panel opening and shutting mechanism L Assembly | [7] OUTDOOR UNIT PARTS    |
| [4] ACCESSORY PARTS                                 | [8] OTHER PARTS           |
|                                                     | [9] OUTDOOR PACKING PARTS |
|                                                     | ■ INDEX                   |

Parts marked with "▲" are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.


# [1] INDOOR UNIT PARTS



NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
<b>[1] INDOOR UNIT PARTS</b>					
1-1	CMOT-A515JBKZ				FAN MOTOR SUB ASS'Y
1-2	DSGY-C542JBKZ				CONTROL BOARD UNIT
1-4	RH-HXA113JBZZ				THERMISTOR K
1-6	RMOT-A174JBZZ				LOUVER MOTOR
1-7	RMOT-A179JBZZ				LOUVER MOTOR VR
1-8	RMOT-A176JBZZ				LOUVER MOTOR VL
1-10	QTANZA054JBZZ				TERMINAL
1-12	CKTTA125AKKZ				PLASUMACLUSTER UNIT
1-17	FSGY-A709JBKZ				DISPLAY BOARD UNIT
1-20	RNF--A001VBE0				FERRITE CORE
1-24	FSGY-A583JBKZ				BOARD UNIT
1-25	QW-VZG044JBZZ				LEAD WIRE
1-26	QW-VZF948JBZZ				LEAD WIRE
1-27	DSGY-C403JBKZ				SENCER PWB UNIT
1-28	LBND-A014JBE0				FIXING BAND
1-29	QW-VZG165JBZZ				LEAD WIRE
2-19	XTPS723P10000				SCREW
3-1	PBOX-A515JBFB				P.W.B BOX
3-2	PCOV-B475JBWZ				P.W.B BOX COVER
3-3	CCOV-A255JBKZ				CLUSTER COVER ASS'Y
3-4	LHLD-A944JBFB				CLUSTER HOLDER
3-5	PCOV-B501JBFA				FRONT PANEL COVER L SE
3-6	PCOV-B502JBFA				FRONT PANEL COVER R SE
3-7	PCOV-B467JBFA				COVER
3-10	DCOV-A298JBKZ				SCREW COVER K[PANEL SIDE]
3-11	PCOV-B476JBWZ				TERMINAL COVER
3-12	PCOV-B503JBFB				SCREW COVER[CABINET SIDE]
3-14	CDA i-A046JBKZ				V-LOUVER BASE ASS'Y
3-15	DCHS-A638JBKZ				CABINET DK
3-16	MJNTPA150JBFB				LOUVER LINK
3-17	MJNTPA155JBFA				V-LOUVER-JOINT
3-18	MLOV-A501JBFB				V-LOUVER-A
3-19	MLOV-A502JBFB				V-LOUVER-B
3-20	PDA i-A231JBFA				V-LOUVER BASE
3-21	PFPFPD504JBEZ				INSULATOR A
3-22	PFPFPD505JBEZ				INSULATOR B
3-23	PFPFPD549JBEZ				LOUVER INSULATOR C
3-27	CHLD-A139JBKZ				BEARING ASS'Y
3-31	CPNL-A631JBKZ				PANEL ASS'Y
3-32	JBTN-A012JBFA				PANEL BOTTOM
3-33	MSPR-A188JBEZ				SPLING
3-35	PHOS-A052JBEZ				DRAIN HOSE
3-36	LPLT-A058JBZ				HOSE HOLDAR
3-37	CSRA-A715JBKZ				DRAIN PAN SUB ASS'Y
2-5A-5	GGAD-A069JBTB				WIRE GUARD
2-5B-5	GGAD-A072JBTB				WIRE GUARD R
3-38	MLOV-A503JBFB				AIR FLOW LOUVER
3-39	NBRG-A038JBFA				BEARING C
3-40	PGID-A166JBFA				DRAIN GUIDE
3-41	PGUMMA381JBEZ				DRAIN PLUG
3-42	PCOV-B477JBWZ				COVER
3-43	PDA i-A218JBFA				HOLDER
3-44	CWAK-C834JBKZ				FRONT PANEL ASS'Y
3-46	LHLD-A879JBFA				HOLDER
3-47	PCOV-B381JBFA				COVER
3-48	PCOV-B526JBFB				COVER
3-49	HPNL-B019JBRA				FILTER COVER
3-50	PFILMA249JBEA				AIR FILTER
3-53	LHLD-A956JBFA				COAD HOLDER
3-54	LHLD-A960JBFB				HOLDER
3-55	LHLD-A933JBFA				LED HOLDER
3-56	PCOV-B533JBFA				LED GUIDE
3-57	HDECQA231JBRA				DISPLAY PANEL
3-58	LHLD-A945JBFB				PANEL
3-59	LHLD-A946JBFB				PANEL BASE R
3-60	LHLD-A948JBFA				SW BUTTON
3-61	LPIN-A010JBEZ				PIN C
3-62	PFTA-A125JBFB				COVER
3-63	XPSSJ20-12000				SPRING PIN
3-64	PCOV-B521JBFA				COVER S
3-65	LHLD-A394JBFA				PIPE HOLDER
3-66	LHLD-A947JBFB				BEARING SUPPORT
3-67	LHLD-A951JBFA				PIPE HOLDER
3-68	NFANCA116JBEZ				CROSS FLOW FAN
3-69	PCOV-B525JBFB				COVER B (screws)
3-70	PFTA-A124JBFB				COVER
3-71	PPLT-A661JBFB				SIDE COVER R
3-72	DCOV-A293JBKZ				COVER ASS'Y
3-74	PSHE-A294JBEZ				SHEET
3-80	PDA i-A240JBWZ				PLATE
10-1	TSPC-G275JBRA				NAME BADGE
10-6	TLABCC505JBRZ				WIRING DIAGRAM
5-0	DEVA-A407JBKZ				EVAPORATOR ASS'Y
5-1	CPIPCB213JBKZ				TUBE ASS'Y
5-3	PCOV-B485JBFB				COVER L


NO.	PARTS CODE	PRICE RANK	N E W M A R K	PART RANK	DESCRIPTION
<b>[1] INDOOR UNIT PARTS</b>					
5-9	LBNDA046JBE0				FIXING BAND
5-10	PFPFPD646JBEZ				INSULATOR
6-1	QW-VZF947JBZZ				LEAD WIRE (for PC unit)
7-2	DPLT-A083JBKZ				MOUNTING ANGLE ASS'Y
7-3	PPLTNA118JBWZ				PIPE GAUGE
8-14	CGID-A047JBKZ				FILTER GUIDE KJH
8-15	CGID-A045JBKZ				FILTER GUIDE K
8-22	LHLD-A995JBFZ				THERMISTOR HOLDER
8-27	LHLD-A991JBFA				GUIDE STRONG
8-28	PGID-A167JBFA				FILTER GUIDE L
8-29	PGID-A168JBFA				FILTER GUIDE R
8-30	PGID-A169JBFA				FILTER GUIDE C

## [2] Panel opening and shutting mechanism R Assembly




NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
<b>[2] Panel opening and shutting mechanism R Assembly</b>					
2-15	CBOX-A053JBKZ				PANEL MECHANISM R ASS'Y
2-1	LHLD-A943JBFB				HOOK
2-3	LPIN-A009JBEZ				PIN
2-4	MARMPA067JBMA				GEAR-C
2-5	MCAMPA010JBZF				CAM R
2-6	NGER-A040JBEZ				GEAR 24
2-7	NGER-A041JBEZ				GEAR 35
2-8	NSFT-A047JBZF				HOOK ARM
2-9	PCAS-A076JBFA				CASE RC
2-10	PCAS-A077JBFA				CASE RA
2-11	PCAS-A078JBFA				CASE RB
2-12	QSW-MA013JBZZ				SWITCH
2-13	RMOT-A164JBZZ				STEPPING MOTOR
2-14	RMOT-A172JBZZ				STEPPING MOTOR
2-16	MCAMPA012JBZF				CAM
2-17	NBRGPA001JBEZ				BEARING
2-18	QW-VZF950JBZZ				LEAD WIRE
2-19	XTPS723P12000				TAPPING SCREW
2-20	XUPS740P10000				SCREW

### [3] Panel opening and shutting mechanism L Assembly




NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
<b>[3] Panel opening and shutting mechanism L Assembly</b>					
2-35	CBOX-A054JBKZ				PANEL MECHANISM L ASS'Y
2-21	LHLD-A943JBFB				HOOK
2-23	LPIN-A009JBEZ				PIN
2-24	MARMPA067JBMA				GEAR-C
2-26	MCAMPA012JBZF				CAM
2-27	MCAMPA013JBZF				CAM L
2-28	NGER-A041JBEZ				GEAR 35
2-29	NSFT-A047JBZF				HOOK ARM
2-30	PCAS-A079JBFA				CASE LC
2-31	PCAS-A080JBFA				CASE LA
2-32	PCAS-A081JBFA				CASE LB
2-33	QSW-MA013JBZZ				SWITCH
2-34	QW-VZF949JBZZ				LEAD WIRE
2-36	NBRGPA001JBEZ				BEARING
2-37	NGER-A040JBEZ				GEAR 24
2-38	RMOT-A167JBZZ				STEPPING MOTOR
2-39	RMOT-A173JBZZ				STEPPING MOTOR
2-40	XUPS740P10000				SCREW

## [4] ACCESSORY PARTS




NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
<b>[4] ACCESSORY PARTS</b>					
7-4	UBATUA027JBE0				BUTTERY
7-5	FFZK-A247JBKZ				SCREWS KIT
7-11	CRMC-A768JBEZ				REMOTE CONTROLER
7-14	USPT-A003CDEZ				SPIUT
7-15	LHLD-A998JBKZ				COVER (for Cabele)
7-16	TINS-B168JBRZ				INSTALLATION MANUAL
7-18	TINSEA569JBRZ				OPERATION MANUAL
7-19	CFIL-A106JBKZ				PURIFY FILTER ASS'Y
<b>[5] OTHER PARTS</b>					
1-22	QFS-GA078JBZZ				FUSE (3.15A 250V)
1-23	VHVTNR9V511-A+				VARISTOR
5-1-2	PSEN-A070JBKZ				FLERE NUT ASS'Y 3/8
5-1-5	PSEN-A071JBKZ				FLERE NUT ASS'Y 1/4
10-2	TLAB-D386JBRZ				ERROR CODE LABEL
10-3	TLAB-D387JBRZ				URGENT LABEL
10-4	TLAB-D388JBRZ				SERVICE LABEL
10-5	TLAB-D472JBEZ				EU-ENERGY LABEL
11-5	LX-BZA075JBE0				SPECIAL SCREW
11-8	XTPS723P14000				SCREW
11-9	XTPS730P10000				SCREW
11-10	XTPS740P08000				SCREW
11-11	XTPS740P12000				SCREW
11-12	XTPS740P14000				SCREW
11-14	XTTS740P10000				SCREW
11-15	XTTS740P12000				SCREW
11-16	XTTS740P14000				SCREW
11-18	XTTS740P20000				SCREW
11-21	XTPS740P16000				SCREW
11-22	QW-VZG030JBZZ				LEAD WIRE BLUE
11-23	QW-VZG031JBZZ				LEAD WIRE 5P
11-24	QW-VZG032JBZZ				LEAD WIRE 6P
11-25	QW-VZG033JBZZ				LEAD WIRE

## [6] INDOOR PACKING PARTS



NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
<b>[6] INDOOR PACKING PARTS</b>					
9-1	SPAKCC558JBEZ				PACKING CASE
9-2	SPADBA448JBEZ				PAD R
9-3	SPADBA449JBEZ				PAD L
9-4	SPADBA462JBEZ				CABI PAD
9-5	SASKAA106JBEZ				BAG
9-6	SPAKCJ944YDEZ				CASE

## [7] OUTDOOR UNIT PARTS




NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
<b>[7] OUTDOOR UNIT PARTS</b>					
1-1	CMOTLB078JBZ				FAN METER
1-2	DSGY-C541JBKZ				CONTROL BOARD UNIT
1-2-6	RH-iXA856JBZZ				IPM
1-2-7	VHDD25XB60+-F				DIODE BRIDGE
1-4	RCiLZA027JBZZ				REACTOR
1-5	RTHM-A022JBEO				THERMISTOR
1-6	QTANZA053JBZZ				TERMINAL BOARD
1-7	FW-VZA070JBKZ				WIRE
1-10	RFiL-A126JBZZ				FERRITE CORE
1-11	RH-HXA029JBZZ				THERMISTOR ASS'Y
1-12	LX-BZA075JBEO				SPECIAL SCREW
2-1	LANGKA227JBZ				MOTOR ANGLE
2-2	CCAB-A408JBKZ				TOP PLATE ASS'Y
2-3	TLABC501JBRZ				WIRING DIAGRAM
2-4	LX-BZA355JBZ				SPECIAL SCREW
2-5	LX-NZA312JBZ				SPECIAL NUT
2-7	CFTA-A268JBKZ				COVER
2-7-1	PCOV-A594JBZ				TERMINAL COVER
2-7-2	PFTA-A090JBFA				COVER
2-7-3	PSEL-C025JBZ				SEALNET SEAL
2-7-4	PSEL-C225JBZ				SEAL
2-7-5	PSEL-C116JBZ				CONDENSER SEAL
2-7-6	PSEL-C157JBZ				SEAL
2-8	PRDAFA211JBZ				HEAT SINK
2-9	LHLD-A684JBFA				HOLDER
2-10	LHLD-A685JBFA				HOLDER
2-11	DBOX-A077JBWZ				CONTROL BOX ASS'Y
2-12	PDAi-A239JBWZ				TERMINAL HOLDER
2-13	PCOV-A595JBZ				COVER
2-14	PSKR-A284JBZ				BULKHEAD
2-15	GCAB-A220JBTA				FRONT PANEL
2-16	GGADPA007JBFA				FAN GUARD
2-17	JHNDPA015JBFA				HANDLE
2-18	LHLD-A449JBFO				THERMISTOR HOLDER
2-19	LHLD-0079SRFO				CORD CLAMP
2-20	LHLD-A699JBFA				HOLDER BASE
2-21	MSPR-A026JBEO				SPRING
2-22	TLAB-C814JBRZ				LABEL
2-23	MSPR-A036JBEO				THERMISTOR SPRING
2-24	MSPR-A143JBZ				SPRING
2-25	NFANPA118JBZ				PROPELLER FAN
2-26	PPLT-A663JBTA				SIDE COVER R
2-27	PSPF-B004JBZ				COMP COVER TOP
2-28	PSPF-B005JBZ				COMPRESSOR COVER
2-31	TLAB-C511JBRA				LABEL
2-32	TLABBA160JBRA				IVT LABEL
2-33	TSPC-G274JBRZ				NAME LABEL
2-34	PPLT-A195JBTA				SIDE COVER L
2-35	PSEL-C830JBZ				SEAL
2-36	CHET-A025JBZ				HEATER ASS'Y
2-37	PCOV-A997JBWZ				COVER
2-38	PSEL-C685JBZ				SEAL
2-39	PSEL-C686JBZ				SEAL
2-39-2	PSEL-C769JBZ				SEAL
2-39-3	PSEL-C684JBZ				SEAL
2-39-4	PSEL-D053JBZ				INSULATOR
2-39-5	PSEL-D052JBZ				INSULATOR
2-39-6	PSEL-C345JBZ				SEAL
2-39-7	PSEL-C767JBZ				SEAL
2-40	PSEL-C029JBZ				SEAL A
2-41	PSEL-C222JBZ				SEAL B
2-42	PSEL-C270JBZ				SEAL
2-43	PFPFPD261JBZ				INSULATOR
2-44	PFPFPD262JBZ				INSULATOR
2-45	PSEL-C356JBZ				CONDENSER SEAL
2-46-1	PSEL-C341JBZ				SEAL SIDE-R
2-46-2	PSEL-C340JBZ				SEAL SIDE-R
2-46-3	PSEL-C339JBZ				SEAL
2-47-1	PSEL-C342JBZ				SEAL
2-48-1	PSEL-C338JBZ				SEAL TOP
2-48-2	PSEL-C337JBZ				SEAL TOP
2-56	PSEL-C030JBZ				CONDENSER SEAL
2-57	PSEL-D063JBZ				INSULATOR
2-58	PSEL-0194SRE0				SEAL
2-59	PSEL-C491JBZ				F-PANEL SEAL
3-1	CCHS-A931JBTA				BASE PAN ASS'Y
3-2	DVLV-A857JBKZ				3WAY VALVE UNIT
3-5	DVLV-A757JBKZ				2WAY VALVE UNIT
3-6	CVLV-A913JBKZ				REVERSE VALVE ASS'Y
3-7	DVLV-A662JBKZ				CONTROL VALVE ASS'Y
3-8	CCiL-A142JBKZ				COIL ASS'Y
3-9	PVLVXA074JBZ				REVERSE VALVE
3-10	PDAi-A123JBTA				FLARE COUPLING BASE
3-12	DCON-A488JBZ				CONDENSER ASSY
3-13	FCMPRA204JBKZ				COMPRESSOR

NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
<b>[7] OUTDOOR UNIT PARTS</b>					
3-14	GLEG-A099JBE0				COMPRESSOR CUSHION
3-15	LX-NZA313JBEZ				SPECIAL NUT
3-17	MSPR-A046JBE0				PROTECTOR SPRING
3-18	PCOV-A833JBEZ				TERMINAL COVER
3-19	PSEL-A142JBEZ				TERMINAL GASKET
3-20	PSPF-A977JBEZ				COMPRESSOR COVER
3-21	PSPF-B083JBEZ				COMPRESSOR COVER

**[8] OTHER PARTS**

1-2-1	QFS-CA001JBZZ				FUSE 20A 250V
1-2-2	QFS-GA051JBZZ				FUSE 2A 250V
1-2-3	QFS-GA052JBZZ				FUSE 3.15A 250V
1-2-4	QFS-CA002JBZZ				FUSE 15A 250V
1-2-5	QFS-GA064JBZZ				FUSE 1A 250V
2-50	PSEL-C345JBEZ				SEAL
2-51	PSEL-C684JBEZ				SEAL
2-52	PSEL-C767JBEZ				SEAL
2-53	PSEL-C769JBEZ				SEAL
3-7-1	RMOTSA023JBZZ				COIL

**[9] OUTDOOR PACKING PARTS**

NO.	PARTS CODE	PRICE RANK	NEW MARK	PART RANK	DESCRIPTION
<b>[9] OUTDOOR PACKING PARTS</b>					
90-1	CPADBA048JBKZ				TOP PAD ASS'Y
90-2	CPADBA049JBKZ				BOTTOM PAD ASS'Y
90-3	SPAKCC557JBEZ				PACKING CASE

**■INDEX**

PARTS CODE	No.	PRICE RANK	NEW MARK	PART RANK
<b>【 C 】</b>				
CBOX-A053JBKZ	2-2-15			
CBOX-A054JBKZ	3-2-35			
CCAB-A408JBKZ	7-2-2			
CCHS-A931JBTA	7-3-1			
CCIL-A142JBKZ	7-3-8			
CCOV-A255JBKZ	1-3-3			
CDAI-A046JBKZ	1-3-14			
CFIL-A106JBKZ	4-7-19			
CFTA-A268JBKZ	7-2-7			
CGID-A045JBKZ	1-8-15			
CGID-A047JBKZ	1-8-14			
CHET-A025JBKZ	7-2-36			
CHLD-A139JBKZ	1-3-27			
CKTTA125AKKZ	1-1-12			
CMOT-A515JBKZ	1-1-1			
CMOTLB078JBEZ	7-1-1			
CPADBA048JBKZ	9-90-1			
CPADBA049JBKZ	9-90-2			
CPICB213JBKZ	1-5-1			
CPNL-A631JBKZ	1-3-31			
CRMC-A768JBEZ	4-7-11			
CSRA-A715JBKZ	1-3-37			
CVLV-A913JBKZ	7-3-6			
CWAK-C834JBKZ	1-3-44			
<b>【 D 】</b>				
DBOX-A077JBWZ	7-2-11			
DCHS-A638JBKZ	1-3-15			
DCON-A488JBPZ	7-3-12			
DCOV-A293JBKZ	1-3-72			
DCOV-A298JBKZ	1-3-10			
DEVA-A407JBKZ	1-5-0			
DPLT-A083JBKZ	1-7-2			
DSGY-C403JBKZ	1-1-27			
DSGY-C541JBKZ	7-1-2			
DSGY-C542JBKZ	1-1-2			
DVLV-A662JBKZ	7-3-7			
DVLV-A757JBKZ	7-3-5			
DVLV-A857JBKZ	7-3-2			
<b>【 F 】</b>				
FCMPRA204JBKZ	7-3-13			
FFZK-A247JBKZ	4-7-5			
FSGY-A583JBKZ	1-1-24			
FSGY-A709JBKZ	1-1-17			
FW-VZA070JBKZ	7-1-7			
<b>【 G 】</b>				
GCAB-A220JBTA	7-2-15			
GGAD-A069JBTA	1-2-5A-5			
GGAD-A072JBTA	1-2-5B-5			
GGADPA007JBFA	7-2-16			
GLEG-A099JBE0	7-3-14			
<b>【 H 】</b>				
HDECQA231JBRA	1-3-57			
HPNL-B019JBRA	1-3-49			
<b>【 J 】</b>				
JBTN-A012JBFA	1-3-32			
JHNDPA015JBFA	7-2-17			
<b>【 L 】</b>				
LANGKA227JBPZ	7-2-1			
LBND-A014JBE0	1-1-28			
LBND-A046JBE0	1-5-9			
LHLD-0079SRFO	7-2-19			
LHLD-A394JBFA	1-3-65			
LHLD-A449JBFO	7-2-18			
LHLD-A684JBFA	7-2-9			
LHLD-A685JBFA	7-2-10			
LHLD-A699JBFA	7-2-20			
LHLD-A879JBFA	1-3-46			
LHLD-A933JBFA	1-3-55			
LHLD-A943JBFB	2-2-1			
"	3-2-21			
LHLD-A944JBFB	1-3-4			
LHLD-A945JBFB	1-3-58			
LHLD-A946JBFB	1-3-59			
LHLD-A947JBFZ	1-3-66			
LHLD-A948JBFA	1-3-60			
LHLD-A951JBFA	1-3-67			
LHLD-A956JBFA	1-3-53			
LHLD-A960JBFZ	1-3-54			

PARTS CODE	No.	PRICE RANK	NEW MARK	PART RANK
LHLD-A991JBFA	1-8-27			
LHLD-A995JBHZ	1-8-22			
LHLD-A998JBKZ	4-7-15			
LPIN-A009JBEZ	2-2-3			
"	3-2-23			
LPIN-A010JBEZ	1-3-61			
LPLT-A058JBPZ	1-3-36			
LX-BZA075JBE0	5-11-5			
"	7-1-12			
LX-BZA355JBEZ	7-2-4			
LX-NZA312JBEZ	7-2-5			
LX-NZA313JBEZ	7-3-15			
<b>【 M 】</b>				
MARMPA067JBMA	2-2-4			
"	3-2-24			
MCAMPA010JBFZ	2-2-5			
MCAMPA012JBFZ	2-2-16			
"	3-2-26			
MCAMPA013JBFZ	3-2-27			
MJNTPA150JBFB	1-3-16			
MJNTPA155JBFA	1-3-17			
MLOV-A501JBFB	1-3-18			
MLOV-A502JBFB	1-3-19			
MLOV-A503JBFB	1-3-38			
MSPR-A026JBE0	7-2-21			
MSPR-A036JBE0	7-2-23			
MSPR-A046JBE0	7-3-17			
MSPR-A143JBEZ	7-2-24			
MSPR-A188JBEZ	1-3-33			
<b>【 N 】</b>				
NBRG-A038JBFA	1-3-39			
NBRGPA001JBEZ	2-2-17			
"	3-2-36			
NFANCA116JBEZ	1-3-68			
NFANPA118JBEZ	7-2-25			
NGER-A040JBEZ	2-2-6			
"	3-2-37			
NGER-A041JBEZ	2-2-7			
"	3-2-28			
NSFT-A047JBFZ	2-2-8			
"	3-2-29			
<b>【 P 】</b>				
Parts Code	0-Reff. No.			
PBOX-A515JBFZ	1-3-1			
PCAS-A076JBFA	2-2-9			
PCAS-A077JBFA	2-2-10			
PCAS-A078JBFA	2-2-11			
PCAS-A079JBFA	3-2-30			
PCAS-A080JBFA	3-2-31			
PCAS-A081JBFA	3-2-32			
PCOV-A594JBPZ	7-2-7-1			
PCOV-A595JBFB	7-2-13			
PCOV-A833JBEZ	7-3-18			
PCOV-A997JBWZ	7-2-37			
PCOV-B381JBFA	1-3-47			
PCOV-B467JBFA	1-3-7			
PCOV-B475JBWZ	1-3-2			
PCOV-B476JBWZ	1-3-11			
PCOV-B477JBWZ	1-3-42			
PCOV-B485JBFB	1-5-3			
PCOV-B501JBFA	1-3-5			
PCOV-B502JBFA	1-3-6			
PCOV-B503JBFB	1-3-12			
PCOV-B521JBFA	1-3-64			
PCOV-B525JBFB	1-3-69			
PCOV-B526JBFB	1-3-48			
PCOV-B533JBFA	1-3-56			
PDAI-A123JBTA	7-3-10			
PDAI-A218JBFA	1-3-43			
PDAI-A231JBFA	1-3-20			
PDAI-A239JBWZ	7-2-12			
PDAI-A240JBWZ	1-3-80			
PFLM249JBEA	1-3-50			
PFPPFPD261JBEZ	7-2-43			
PFPPFPD262JBEZ	7-2-44			
PFPPFPD504JBEZ	1-3-21			
PFPPFPD505JBEZ	1-3-22			
PFPPFPD549JBEZ	1-3-23			
PFPPFPD646JBEZ	1-5-10			

PARTS CODE	No.	PRICE RANK	NEW MARK	PART RANK
PFTA-A090JBFA	7-2-7-2			
PFTA-A124JBFB	1-3-70			
PFTA-A125JBFB	1-3-62			
PGID-A166JBFA	1-3-40			
PGID-A167JBFA	1-8-28			
PGID-A168JBFA	1-8-29			
PGID-A169JBFA	1-8-30			
PGUMMA381JBEZ	1-3-41			
PHOS-A052JBEZ	1-3-35			
PPLT-A195JBTA	7-2-34			
PPLT-A661JBZF	1-3-71			
PPLT-A663JBTA	7-2-26			
PPLTNA118JBWZ	1-7-3			
PRDAFA211JBEZ	7-2-8			
PSEL-0194SRE0	7-2-58			
PSEL-A142JBEZ	7-3-19			
PSEL-C025JBEZ	7-2-7-3			
PSEL-C029JBEZ	7-2-40			
PSEL-C030JBEZ	7-2-56			
PSEL-C116JBEZ	7-2-7-5			
PSEL-C157JBEZ	7-2-7-6			
PSEL-C222JBEZ	7-2-41			
PSEL-C225JBEZ	7-2-7-4			
PSEL-C270JBEZ	7-2-42			
PSEL-C337JBEZ	7-2-48-2			
PSEL-C338JBEZ	7-2-48-1			
PSEL-C339JBEZ	7-2-46-3			
PSEL-C340JBEZ	7-2-46-2			
PSEL-C341JBEZ	7-2-46-1			
PSEL-C342JBEZ	7-2-47-1			
PSEL-C345JBEZ	7-2-39-6			
"	8-2-50			
PSEL-C356JBEZ	7-2-45			
PSEL-C491JBEZ	7-2-59			
PSEL-C684JBEZ	7-2-39-3			
"	8-2-51			
PSEL-C685JBEZ	7-2-38			
PSEL-C686JBEZ	7-2-39			
PSEL-C767JBEZ	7-2-39-7			
"	8-2-52			
PSEL-C769JBEZ	7-2-39-2			
"	8-2-53			
PSEL-C830JBEZ	7-2-35			
PSEL-D052JBEZ	7-2-39-5			
PSEL-D053JBEZ	7-2-39-4			
PSEL-D063JBEZ	7-2-57			
PSEN-A070JBKZ	5-5-1-2			
PSEN-A071JBKZ	5-5-1-5			
PSHE-A294JBEZ	1-3-74			
PSKR-A284JBZ	7-2-14			
PSPF-A977JBEZ	7-3-20			
PSPF-B004JBEZ	7-2-27			
PSPF-B005JBEZ	7-2-28			
PSPF-B083JBEZ	7-3-21			
PVLVXA074JBEZ	7-3-9			
<b>[ Q ]</b>				
QFS-CA001JBZZ	8-1-2-1			
QFS-CA002JBZZ	8-1-2-4			
QFS-GA051JBZZ	8-1-2-2			
QFS-GA052JBZZ	8-1-2-3			
QFS-GA064JBZZ	8-1-2-5			
QFS-GA078JBZZ	5-1-22			
QSW-MA013JBZZ	2-2-12			
"	3-2-33			
QTANZA053JBZZ	7-1-6			
QTANZA054JBZZ	1-1-10			
QW-VZF947JBZZ	1-6-1			
QW-VZF948JBZZ	1-1-26			
QW-VZF949JBZZ	3-2-34			
QW-VZF950JBZZ	2-2-18			
QW-VZG030JBZZ	5-11-22			
QW-VZG031JBZZ	5-11-23			
QW-VZG032JBZZ	5-11-24			
QW-VZG033JBZZ	5-11-25			
QW-VZG044JBZZ	1-1-25			
QW-VZG165JBZZ	1-1-29			
<b>[ R ]</b>				
RCILZA027JBZZ	7-1-4			
RFL-L-A126JBZZ	7-1-10			
RH-HXA029JBZZ	7-1-11			
RH-HXA113JBZZ	1-1-4			
RH-IXA856JBZZ	7-1-2-6			

PARTS CODE	No.	PRICE RANK	NEW MARK	PART RANK
RMOT-A164JBZZ	2-2-13			
RMOT-A167JBZZ	3-2-38			
RMOT-A172JBZZ	2-2-14			
RMOT-A173JBZZ	3-2-39			
RMOT-A174JBZZ	1-1-6			
RMOT-A176JBZZ	1-1-8			
RMOT-A179JBZZ	1-1-7			
RMOTSA023JBZZ	8-3-7-1			
RNF--A001VBE0	1-1-20			
RTHM-A022JBEO	7-1-5			
<b>[ S ]</b>				
SPADBA448JBEZ	6-9-2			
SPADBA449JBEZ	6-9-3			
SPADBA462JBEZ	6-9-4			
SPAKCC557JBEZ	9-90-3			
SPAKCC558JBEZ	6-9-1			
SPAKCJ944YDEZ	6-9-6			
SSAKAA106JBEZ	6-9-5			
<b>[ T ]</b>				
TINS-B168JBRZ	4-7-16			
TINSEA569JBRZ	4-7-18			
TLABBA160JBRA	7-2-32			
TLAB-C511JBRA	7-2-31			
TLAB-C814JBRZ	7-2-22			
TLABCC501JBRZ	7-2-3			
TLABCC505JBRZ	1-10-6			
TLAB-D386JBRZ	5-10-2			
TLAB-D387JBRZ	5-10-3			
TLAB-D388JBRZ	5-10-4			
TLAB-D472JBEZ	5-10-5			
TSPC-G274JBRZ	7-2-33			
TSPC-G275JBRA	1-10-1			
<b>[ U ]</b>				
UBATUA027JBEO	4-7-4			
USPT-A003CDEZ	4-7-14			
<b>[ V ]</b>				
VHDD25XB60+-F	7-1-2-7			
VHVTNR9V511-A+	5-1-23			
<b>[ X ]</b>				
XPSJJ20-12000	1-3-63			
XTPS723P10000	1-2-19			
XTPS723P12000	2-2-19			
XTPS723P14000	5-11-8			
XTPS730P10000	5-11-9			
XTPS740P08000	5-11-10			
XTPS740P12000	5-11-11			
XTPS740P14000	5-11-12			
XTPS740P16000	5-11-21			
XTTS740P10000	5-11-14			
XTTS740P12000	5-11-15			
XTTS740P14000	5-11-16			
XTTS740P20000	5-11-18			
XUPS740P10000	2-2-20			
"	3-2-40			

